




A custom-fit cover is available for each of our sectional components. Components are named by the position of the arm *as you face the piece*.




Corner Chair Cover




Rounded Corner Chair Cover




Armless Chair Cover




Two-Seater Armless Sofa Cover




Three-Seater Armless Sofa Cover




Left-Arm Chair Cover




Right-Arm Chair Cover




Left-Arm Chaise Cover




Right-Arm Chaise Cover




Left-Arm Sofa Cover




Right-Arm Sofa Cover



Round Armless Sofa Cover



Round Left-Arm Sofa Cover




Round Right-Arm Sofa Cover


## FEATURES

Custom-made to fit our outdoor sectionals, our covers offer superior performance and are made of breathable Sur Last® fabric that's highly resistant to mold, tearing and fading. They're the design industry's choice for protecting furniture from dust and dirt, harsh ultraviolet rays and inclement weather.


- Custom-made to sectional collections
- Durable Sur Last® fabric is 100% solution-dyed polyester
- Breathable fabric resists mold and mildew
- Resists shrinkage, fading, UV rays and harsh weather
- Holds its shape without tearing or stretching
- Highly water-resistant
- Covers zip together easily
- Secures with straps and a self-release buckle
- 3-year limited warranty



For a sectional configuration with 2 armless sides, you'll need to purchase a left end panel and a right end panel.



For a sectional configuration with one armless side, you'll need to purchase one (left or right) end panel.



Sectional configurations with arms at both ends do not require separate end panels.

## HOW TO USE

If your sectional configuration is armless on one or both sides, you will need to purchase either one or two end panels for complete coverage, as shown above.

1. Arrange your sectional furniture as you normally configure it.
2. If your furniture comes with back cushions, lay them down flat on the seat(s) before putting the cover on. This will allow the cover to fit properly.
3. Place each cover over the appropriate piece of furniture; the side that has the long strap attached goes in the back.
4. Zip covers together from the back to the front.
5. Bring straps underneath the furniture from back to front and buckle to keep covers secure.

## CARE

Before placing covers on furniture, spray off any debris with a hose and wipe furniture dry with a soft cloth; residue trapped on the surface can

create mold.

For ongoing care of covers, spray off any dirt or debris with a hose once a month. A more rigorous cleaning will be needed every 2-3 years; use a soft bristle brush and a cleaning mixture of cold or lukewarm water (under 100°F) and mild, natural soap. Avoid harsh detergents.

For stubborn stains, apply a mixture of diluted chlorine bleach and water. Lightly spray mixture on the fabric (non-coated side). Do not soak fabric for more than 2 minutes; prolonged exposure to harsh chemicals can damage the interior lining.

Rinse thoroughly. Air dry only.

## WARRANTY

Three-year limited warranty covering manufacturing defects that include seam separation and/or zipper failure. The fabric carries a three-year limited warranty against loss of function due to loss of color or strength from normal usage and exposure conditions, including sunlight, mildew and atmospheric chemicals. Consumer is responsible for normal care and cleaning of the fabric.