

RESTORATION HARDWARE

ESTATE FINIALS ASSEMBLY INSTRUCTIONS

To fit the Estate finials onto custom rods:

1. Fit the Estate finials onto the ends of the Custom rod. (see
2. Use the included Allen Wrench to tighten the set-screw on
3. Rod and finial assembly is complete. (see Fig A-3)






Fig A-1)



the lip of the finials. (see Fig A-2)



To fit the Estate finials onto telescoping rods:

1. Pull the inner rod out of outer rod a minimum of 1 inch. (see
2. Fit the Estate finials onto the ends of the rod. (see Fig B-2)
3. Use the included Allen Wrench to tighten the set-screw on
4. Rod and finial assembly is complete. (see Fig B-4)





Fig B-1)



the lip of the finials. (see Fig B-3)

