

RESTORATION HARDWARE

SPANISH TORCH ROUND 60 INCH CHANDELIER

PARTS ENCLOSED: HARDWARE INCLUDED:

- | | |
|---------------------------|--------------------------------|
| (A) Fixture stud (1) | (a) Plastic wire connector (3) |
| (B) Canopy (1) | (b) Toggle (4) |
| (C) Lock ring (1) | (c) Screw (4) |
| (D) Loop (1) | (d) Lock (1) |
| (E) Base (1) | (e) Safety cable (1) |
| (F) Fixture stud loop (1) | |
| (G) Chain link (2) | |
| (H) Bulb (15) | |

IMPORTANT SAFETY INSTRUCTIONS:

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.
This fixture has been rated for up to (15) 40-watt maximum TYPE CA bulb.
To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off lamp and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.
Keep flammable materials away from lit bulb.

This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Shut off electrical supply at main fuse box / circuit breaker. A licensed electrician should install this fixture.
3. Connect the Loop (D) and the lower Chain link (G). Connect the Fixture stud loop (F) and the upper Chain link (G).
4. Attach the Safety cable (e) to the fixed fixture on the ceiling with the Lock (d).
5. Attach the ground wire from the fixture to the ground junction box wire from the outlet box (Usually green or bare wire) with a plastic wire connector(a) and wrap the connection with electrical tape.
6. Connect the hot wire to the hot junction box wire (usually black or smooth) with a plastic wire connector(a) and wrap the connection with electrical tape. Connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a plastic wire connector(a) and wrap the connection with electrical tape.
7. Attach Fixture stud (A) to ceiling beam through outlet box . Have professional contractor reinforce ceiling.
8. Attach the Canopy (B) to the Fixture stud (A) using the Lock ring(C) and tighten it.
9. Insert the bulbs (included) into threaded sockets.
10. Restore power to the junction box and test lamp fixture.
11. Installation is complete.

CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp.
JUST WIPE CLEAN WITH SOFT CLOTH.

