

Step 1

Insert 1/2" carriage bolts through bottom of GVS base.

Please note: galvanized steel plate should have the recessed holes on the bottom.

Step 2

Mount deck mount and gasket.

Step 3

Insert lock washers and tighten nuts.

