RESTORATION HARDWARE BAYONNE FINIAL ATTACHMENT ASSEMBLY INSTRUCTIONS

ASSEMBLY INSTALLATION

Enclosed connector should be used on the rods which are cut. Please follow below steps to assembly the finials.

- 1. Attach the finial attachment onto the end of the rod, and tighten the set-screw with the enclosed Allen Wrench (See Fig 1).
- 2. Screw the finials into the finial attachment (See Fig 1).

