

# RESTORATION HARDWARE

## PAUILLAC SCONCE

### PARTS ENCLOSED:    **HARDWARE INCLUDED:**

- |                    |                                |
|--------------------|--------------------------------|
| (A) Back plate (1) | (a) Plastic wire connector (3) |
| (B) Base (1)       | (b) Anchor (4)                 |
| (C) Bulb (1)       | (c) Anchor screw (4)           |
| (D) Shade (1)      |                                |

### IMPORTANT SAFETY INSTRUCTIONS:

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.  
This fixture has been rated for up to (1) 40-watt maximum TYPE T bulb.  
To avoid the risk of fire, do not exceed the recommended wattage.

### WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off lamp and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.  
Keep flammable materials away from lit bulb.

This lighting fixture contains lead, a chemical know to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

### TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Shut of electrical supply at main fuse box / circuit breaker. A licensed electrician should install this fixture.
3. Mark the location of the back plate holes on the wall using a pencil. using the marks as a guide, drill holes for the Anchors (b). insert the anchors into the holes, using a hammer to fully insert until flush with the ceiling.
4. Attach the ground wire from the fixture to the ground junction box wire from the outlet box (Usually green or bare wire) with a plastic wire connector(a) and wrap the connection with electrical tape.
5. Connect the hot wire to the hot junction box wire (usually black or smooth) with a plastic wire connector(a) and wrap the connection with electrical tape. Connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a plastic wire connector(a) and wrap the connection with electrical tape.
6. Attach Back plate (A) onto the wall outlet box using four Anchor screws (c). Screw the Anchor screws (c) into the Anchors (b) using a screwdriver.
7. Insert the bulb (included) into threaded socket. And put the Shade(D) onto the Base(B).
8. Restore power to the junction box and test lamp fixture.
9. Installation is complete.

### CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp.  
JUST WIPE CLEAN WITH SOFT CLOTH.

