
RH Marais Pull Installation Instructions

This pull includes hardware that is designed to mount securely to drawer fronts or cabinet doors that have a thickness range between ½ inch and 1¼ inches. If your drawer front or door is thicker or thinner than this range, please obtain the appropriate size screw from your local hardware store.

PARTS INCLUDED

- 1 pc Drawer Pull
- 2 pcs 8-32, 1" Truss Head Machine Screw with Washer
- 1. Carefully determine a desired pull location and use a 3/16"-diameter drill bit and an appropriate drill to make the hole through the drawer/door front.
- 2. Insert the appropriate length screw.
- 3. Attach the pull onto the protruding threads of the screw and rotate clockwise until snug. Use a screwdriver to tighten the screw while gently holding the pull.



CARE INSTRUCTIONS

Wipe with a soft, dry cloth. To protect the finish, do not use household cleaners or abrasives.