

INSTALLATION INSTRUCTIONS
SHOWERHEAD MODEL NO.
10038402 (RH-2154)

RH

RESTORATION HARDWARE

We recommend Installation of this product by a Professional Plumbing Contractor

Note: Regarding fittings, the use of petroleum based plumber's putty on our products will nullify the warranty. We recommend the use of clear silicone sealing materials as outlined by the manufacturer.

To avoid damage to trim, all mating surfaces,(tile, paint, etc.), should be finished prior to trim installation.

Shower Head Installation:

1. Apply thread sealant to inlet end of SHOWER ARM (1a) and thread into FITTING (2) behind finished wall.
2. Apply a small bead of clear silicone to backside of FLANGE (4), included, and slide over NIPPLE (1) and flush against wall.
3. Apply thread sealant to outlet end of SHOWER ARM (1b) and attach shower HEAD (3).

