RH

PULL

ASSEMBLY AND INSTALLATION INSTRUCTIONS **ENGLISH**

PULL

PARTS INCLUDED

(A) Pull (1)

(B) M5-0.8, 1" (25,4 mm) Truss Head Machine Screw (2)

(C) M5-0.8-, 1.5" (38 mm) Truss Head Machine Screw (2)

THIS PULL INCLUDES HARDWARE THAT IS DESIGNED TO MOUNT SECURELY TO DRAWER FRONTS OR CABINET DOORS THAT HAVE A THICKNESS RANGE BETWEEN ½ INCH (1 CM) AND 1¼ INCHES (3 CM). IF YOUR DRAWER FRONT OR DOOR IS THICKER OR THINNER THAN THIS RANGE, PLEASE OBTAIN THE APPROPRIATE SIZE SCREW FROM YOUR LOCAL HARDWARE STORE.

ASSEMBLY INSTRUCTIONS


- Carefully determine a desired pull location and use a 3/16" (5 mm) - diameter drill bit and an appropriate drill to make the holes through the drawer/door front.
- 2. Insert the appropriate length screw from the inside.
- Attach the pull onto the protruding threads of the screw and use a screwdriver to tighten the screws while gently holding the pull.

WARRANTY

If you are not completely satisfied with your purchase, please contact us to return or exchange your item(s) within 30 days of the delivery date, with proof of purchase. Note that returns or exchanges are not accepted for special orders, items that have been installed, mattresses and/or foundations no longer in their original packaging, and other items listed below. Other exclusions may apply. Contact us for details. Unfortunately, galleries cannot accept returns of furniture or other large items.

CARE INSTRUCTIONS

Wipe with a soft, dry cloth. To protect the finish, do not use household cleaners or abrasives.



Product may differ