

# RH

VAUXHALL HOOK

ASSEMBLY AND INSTALLATION INSTRUCTIONS

**ENGLISH**

**VAUXHALL HOOK**

The enclosed fitting is crafted of forged solid brass. Forging is a process whereby a tool forms and actually compresses the metal with a tremendous amount of force. Each fitting is heated, formed and polished by hand. Our fittings and fixtures for your home are not merely beautiful but will endure for years.

**TOOLS REQUIRED**

- (1) Phillips screwdriver
- (2) Hammer
- (3) Drill
- (4) Pencil

**MOUNTING INSTRUCTIONS**

1. Position wall mount in desired location on wall.
2. After positioning on wall, lightly mark outline of both cover plates.
3. Center mounting brackets as shown, in outline of post. (FIGURE 1)
4. Mark location of dry wall anchor installation. Remove mounting bracket from wall. Position dry wall anchor and gently tap anchor into wall until cap prongs are embedded in wall and cap is snug against surface. Turn screw clockwise, pressing firmly to prevent anchor from rotating. Tighten screw until resistance is felt, this will fully expand the anchor. Turn screw counterclockwise to remove screw-anchor will remain embedded in wall.
5. Place mounting bracket over anchor and reinsert dry wall anchor screw. Place fixture over mounting brackets and tighten set screws.
6. If necessary, loosen wall mounting screws and adjust mounting brackets to obtain proper horizontal alignment on wall. Tighten screws and remount cover plates.

**CLEANING INSTRUCTIONS**

To maintain and protect the luster of all products, clean with a soft, damp cloth only.

**FIGURE 1**