

Step 1

Insert 1/2" carriage bolts through bottom of GVS base.

Please note: galvanized steel plate should have the recessed holes on the bottom.

Step 2

Peel back tab on adhesive tape and secure cover to g-plate.

Step 3

Mount deck mount and gasket.

Step 4

Insert lock washers and tighten nuts.

