


# RH

## RONAN LEATHER-WRAPPED TASK TABLE LAMP

---

### PARTS ENCLOSED

- (A) Lamp Pole (1)
- (B) Threaded Collar (1)
- (C) Plug (1)
- (D) Plug Cover (1)



## IMPORTANT SAFETY INSTRUCTIONS

1. Do not break or pull out LED panel.
2. Indoor use only.
3. Do not look directly at the light.
4. Keep lamp away from materials that may burn.
5. If the supply cord or adaptor is damaged, it must be replaced only by service agent or a qualified technician.

## WARNINGS

All wires are connected. When unpacking, be careful not to pull wires, as a bad connection may result. Do not connect electricity until your fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb. Do not touch or look directly at the bulb when fixture is illuminated. Keep flammable materials away from lit bulb.



**WARNING:** This product can expose you to lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.



**WARNING: STRANGULATION HAZARD**

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3 years of age.

## ASSEMBLY &amp; INSTALLATION

1. Carefully remove all parts from the box and remove all plastic coverings.
2. Remove red Plug Cover (D) from Plug (C).
3. Plug into proper electrical outlet and test fixture.
4. Assembly is complete.

## TO ADJUST HEIGHT

1. Loosen Threaded Collar (B) by turning in a counterclockwise direction.
2. Adjust lamp by pulling or pushing Lamp Pole (A) up or down to desired height.
3. Tighten Threaded Collar (B) by turning in a clockwise direction.

## CARE INSTRUCTIONS

Do not use polishes or cleaners on the lamp. Wipe clean with a soft, dry cloth.