

RESTORATION HARDWARE

Thank you for purchasing Restoration Hardware Lighting. Our assortment is crafted with the highest quality details in mind and each collection is clad in one of our signature finish options. Each item's surface is sealed which eliminates the need for polishing and ensures the lasting brilliance of your piece for years to come.

PARTS ENCLOSED:

- | | |
|----------------------|--------------------|
| (A) CROSS BAR | (K) FORK |
| (B) CROSS BAR SCREWS | (L) SUPPORT |
| (C) THREADED TUBE | (M) DIFFUSER |
| (D) HANG STRAIGHT | (N) ADJUSTMENT KEY |
| (E) EXTENSION | (O) DIFFUSER |
| (F) CANOPY | (P) CLIP |
| (G) COLLAR | |
| (H) EXTENSION | |
| (I) EXTENSION | |
| (J) EXTENSION | |

IMPORTANT SAFETY INSTRUCTIONS:

*These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.

*DIRECT WIRE FIXTURES: WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.

This fixture has been rated for up to (2) 100W MAX. Type A bulbs.

To avoid risk of fire, do not exceed the recommended wattage.

WARNINGS:

Turn off power (unplug from the wall outlet) before replacing the bulb(s), making sure the bulb(s) had sufficient time to cool down.

DO NOT subject the lamp to any shock while lit as shattering of bulb may result.

TO ASSEMBLE:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts from carton. Do not throw away any parts.
3. Remove cross bar (A) from hang straight (D). Affix cross bar (A) to "J BOX" using screws (B) provided.
4. Measure desired drop for fixture to hang and add/remove extension tubes (E, H, I, and J). Guide wiring through extension tubes before threading tubes together. **ADD/REMOVE EXTENSIONS: (Un)Thread the threaded nipple of one extension into the threaded opening of the next extension. To prevent damage, pull wiring tight when threading extensions together.
5. Thread bottom extension tube (E, H, I, or J) into the threaded opening of fork (K).
6. Slide collar (G) and canopy (F) onto extension tube (E). Slide collar (G) and canopy (F) down extension tubes and let rest on fork (K).
7. Lift fixture to "J BOX." Guide wiring through threaded tube (C). Thread hang straight (D) onto threaded tube (C).
8. Make proper electrical connection. A LICENSED ELECTRICIAN IS RECOMMENDED.
9. Connect the grounding wire (green and yellow striped) from the fixture to the grounding wire in the outlet box. Connect the black wire of the fixture (or smooth side of the wire) to the black wire in outlet box. Connect the white wire of the fixture (or rough side of the wire) to the white wire in outlet box. Fasten wires together with a plastic wire connector and tightly wrap connector with electrical tape.
10. Slide canopy (F) up extension tubes and hold tightly against ceiling. Slide collar (G) up extension tubes and thread onto hang straight (D) to hold canopy (F) tightly against the ceiling.
11. Open diffuser frame (M) by unthreading decorative nut on support (L) until support (L) can be rotated away from diffuser frame (M). Repeat for each (L) support. Do not remove decorative nut from support (L).
12. Install two (2) Type A, 100 watt maximum bulbs into sockets.
13. Unthread screws on clip (P) and rotate clip (P) to the side. DO NOT remove clip (P) from diffuser frame (M).
14. Holding diffuser frame (M) as level as possible and place diffuser (O) onto recessed channel inside diffuser frame (M). Rotate clips (P) to hold diffuser (O). Tighten screw on clip (P) to secure diffuser (O).
15. Close diffuser (M) and secure by rotating support (L) down and threading decorative nut up support (L) until decorative nut rest against diffuser (M).
16. Tighten adjustment keys (N) to secure shade to fork (K).

CARE INSTRUCTIONS:

To clean, use a soft cloth only. DO NOT use any chemical or abrasive cleaners.

HARMON PENDANT

