

RESTORATION HARDWARE

Thank you for purchasing Restoration Hardware Lighting. Our assortment is crafted with the highest quality details in mind and each collection is clad in one of our signature finish options. Each item's surface is sealed which eliminates the need for polishing and ensures the lasting brilliance of your piece for years to come.

PARTS ENCLOSED:

- (A) SHADE
- (B) SWIVEL
- (C) ADJUSTMENT KEY
- (D) BASE
- (E) POLARIZED PLUG
- (F) PLUG COVER

IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into the outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (1) 40W MAX. Type G candelabra bulb.
To avoid risk of fire, do not exceed the recommended wattage.

WARNINGS:


Turn off power (unplug from the wall outlet) before replacing the bulb(s), making sure the bulb(s) had sufficient time to cool down.

DO NOT subject the lamp to any shock while lit as shattering of bulb may result.

TO ASSEMBLE:

1. REMOVE ALL PARTS CAREFULLY FROM THE CARTON.
2. Place base (D) on level surface.
3. Loosen adjustment key (C), rotate swivel (B) to desired position. Tighten adjustment key (C) to secure position of lamp.
4. Install one (1) Type G, 40 watt maximum candelabra base bulb into socket located inside shade (A).
5. Remove plug cover (F) from polarized plug (E). Plug lamp into wall outlet.

ATELIER ACCENT LAMP



CARE INSTRUCTIONS:

To clean, use a soft cloth only. DO NOT use any chemical or abrasive cleaners.