

Lot: \_\_\_\_\_

# RESTORATION HARDWARE

Style # 26100037 River Rock Fire Bowl

**For Technical Support contact Real Flame®:  
1-800-654-1704**

**Restoration Hardware Customer Service:  
1-800-816-0901**



**Designed and Engineered by Real Flame.  
Manufactured in China for:  
Restoration Hardware  
15 Koch Rd, Suite J  
Corte Madera, CA 94925**

RH 26100037 Rev6-9-12

**For Technical Support call  
1-800-654-1704**



# ⚠️ WARNINGS ⚠️

Read entire label and all instructions included with ventless fireplace fuel and fire bowl  
PROPERTY DAMAGE, SERIOUS INJURY OR DEATH may result if these warnings are not followed

## HAZARDS

- Ventless Fireplace Fuel is flammable. Failure to follow warnings can result in property damage or serious burns.
- Do not attempt to refill a fire that is already burning. Flare-ups or flashbacks can occur if you do. Make sure that the fire is out and allow the unit to cool for 20 minutes before refueling.
- Use only Real Flame® Ventless Fireplace Fuel in this unit. Do not use with any other fuels or flammable material.
- Do not store or use gasoline or other flammable materials, including fuel, near this product. Vapors from these types of items may collect and increase the risk of fire, explosion or injury.

**In case of an emergency use a CO2 extinguisher or baking soda to extinguish the fire.**

1. Burn only Real Flame® Ventless Fireplace Fuel in fire bowl. Never burn trash, paper, wood or any other fuel in the unit. SEVERE BURN HAZARD
2. Fire bowl is not to be operated by anyone below age 18. Keep away from children and pets.
3. Make sure fire bowl is placed on a flat and level surface. Failure to do so could cause the unit to tip, resulting in serious injury, property damage or death.
4. Do not place fire bowl in an area with lots of traffic, such as a hallway or entryway.
5. WARNING: Never alter or dismantle fire bowl in any manner.
6. Never burn ventless fireplace fuel outside the designated burn area.
7. Do not burn more than the specified amount of fuel at any time.
8. Never leave a burning fire unattended, especially around children or pets.
9. Never touch rocks or any metal surfaces during or immediately after burning ventless fireplace fuel. They will be extremely HOT. Allow surfaces to cool for 20 minutes before touching, refueling, or moving the unit.
10. Do not wear flammable or loose clothing when operating the fire bowl.
11. Exercise the same precautions as you would with any open fire.
12. DEATH, SERIOUS INJURY OR PROPERTY DAMAGE may result if these warning are not followed correctly.

**NOTICE: Buyer assumes all responsibility for safety and use that is not in compliance with these instructions and warnings.**

### Using your Fire Bowl

- Unit is for outdoor use only.
- Before using unit, be sure you have read and understood the step-by-step instructions.
- After several burns, soot may develop on the damper. Clean with a damp soapy rag.
- During the initial burn you may experience a slight odor. Odor is temporary and will be absent on following burns.

### VENTLESS FIREPLACE FUEL

Real Flame® Ventless Fireplace Fuel contains isopropyl alcohol. Avoid contact with eyes, mucous membranes or prolonged contact with skin. May irritate eyes. Store in a cool, dry place. Keep away from flame, heat or items that spark. Use in well-ventilated areas. Keep out of reach of children and pets. In case of fire, use a CO2 fire extinguisher or baking soda.

### FIRST AID

If fuel gets in eyes, flush with water for 15 minutes; get medical attention. If ingested, do not induce vomiting; call poison control center or a doctor.


If you have questions please call customer service at  
1-800-816-0901 Restoration Hardware or 1-800-654-1704 Real Flame

## Care and Cleaning

ALLOW ALL SURFACES TO COOL FOR AT LEAST 20 MINUTES  
BEFORE ATTEMPTING TO CLEAN

Burn trough should be cleaned every two burns. This can be cleaned using the scraper tool included.

- Allow trough to cool completely before attempting to clean.
- Place the straight edge of the scraper into the can and pull along the edge.
- Residue should be thrown away in the trash.



Use a soft cloth and warm soapy water to clean the fire bowl.


Discoloration is normal for stainless steel that is in direct contact with the flame.

# Cover when not in use

The Fire Bowl and all of its components should be cool to the touch before attempting to cover the Fire Bowl.


When the Fire Bowl has cooled down begin by placing the cover (7) over the Fire Bowl.

Use the Velcro® strap as shown below to secure the cover to the Fire Bowl.




Parts List			
Number	Description	Part Number	Quantity
1	Fire Bowl	05302901	1
2	Main Plate	05303102	1
3	Damper	05303103	1
4	Trough	05303104	2
5	Scraper	05303105	1
6	River Rocks	05303106	1 Bag
7	Cover	05303107	1

Hardware Pack	
05300008	
A	⌀ x 3
B	⌀ x 3




## Step One

- Install Main Plate (2) onto the Base (1) using three screws (8) with washers (9).




## Extinguishing

- To extinguish flames use the scraper tool. Place the hole at the end opposite the handle over the pin in the center of the Damper.
- First pull the damper over the flame closest to you. Hold in place for 5-10 seconds and push the damper to the other side. Again hold in place for 5-10 seconds to ensure the flame is extinguished.




## Lighting

- The damper should be centered so that there is an even amount of space open on each trough.
- Light the Real Flame® Ventless Fireplace Fuel using a long lighter or fireplace match.



## Step Two


- Install the Troughs into the open areas of the Main Plate.
- Place the Damper in the center of the Main Plate with the bar protruding from the bottom installed into the long narrow opening in the center. The Damper should be centered on the bowl.






## Step Three

- Spread the river rock evenly on the main plate and within the top of the damper. Any river rocks that fall into the troughs must be removed prior to operating the Fire Bowl.



## FUEL USE

- With the trough in place; fill with Real Flame® Ventless Fireplace fuel only.
- Fill the cup to a maximum of 3/4" from the lip of the cup. DO NOT overfill. Clean up any spills before lighting.



### WARNING: RISK OF EXPLOSION

- Do not attempt to add ventless fireplace fuel to a fire that is already burning.
- Use only Real Flame® Ventless Fireplace Fuel. Do not use with any other fireplace fuel or flammable material.
- Do not store or use gasoline or other flammable materials, including ventless fireplace fuel, near this product. Vapors from these types of items may collect and increase the risk of fire, explosion or injury.
- In case of an emergency use a CO2 extinguisher or baking soda to extinguish the fire.