
RH


ARPEGE CYLINDER PENDANT

PLEASE FOLLOW THE ASSEMBLY INSTRUCTIONS CLOSELY. IMPROPER ASSEMBLY CAN RESULT IN PERSONAL OR PROPERTY DAMAGE. IF YOU ARE UNSURE ABOUT YOUR CEILING TYPE OR WHAT MOUNTING METHOD YOU SHOULD USE, CONSULT A QUALIFIED PROFESSIONAL OR YOUR LOCAL HARDWARE STORE.

PARTS ENCLOSED:

- (A) Mounting Plate (1) (B) 1"L Phillips Flat Head Screw (4) (C) Canopy (1) (D) 3/16"L Hex Socket Set-screw (3) (E) Link A (1) (F) Link B (1) (G) Round Nut (2) (H) 18" Extension Rods (2) (I) 12" Extension Rods (2) (J) 6" Extension Rods (2) (K) Coupling (5) (L) Threaded Head (1) (M) M3 1/4"L Phillips Flat Head Screw (6) (N) Hook Bar (3) (O) Glass Shade (1) (P) Light Bulb (1)
- (Q) Wire (1)





IMPORTANT PLEASE READ

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.

SAFETY INSTRUCTIONS:

This fixture must be mounted to the ceiling independent of an outlet box. Your ceiling may require modification to allow the mounting plate to be secured to a structural member. This fixture MUST NOT be secured using any type of hollow ceiling anchor, such as a toggle bolt.

This fixture has been rated for (1) 40-watt maximum Type T8 standard light bulbs (included). To avoid the risk of fire,do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the light bulb. Do not touch the bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE

🖄 WARNING: STANGULATION HAZARD

Keep cord at least 3 ft away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3.

ASSEMBLY & INSTALLATION:

- 1. Carefully remove all parts from the box and remove all plastic covering.
- 2. Determine the hanging length of pendant. Connect Threaded Head (L) to some or all Connection Rods (H) (I) (J) & Couplings (K) according to the height needed. Add Round Nut (G) recessed in Connection Rods at both ends to keep center position, and then Connect Link B (F) to Connection Rods.
- 3. Use Link A (E) to Connect Link B (F) & Canopy together, Attach Link A (E) to Canopy (C) and secure with (x2) 1"L Phillips Flat Head Screw (B) on backside of the Canopy (C).
- 4. Feed wires through the Connection Rods; the wires will come out on the backside of the Canopy (C); WARNING: DO NOT REMOVE THE AUXILIARY ELECTRICAL TAP ON WIRE FOR FEEDING WIRES.(See Fig.1.)
- 5. Attach Mounting Plate (A) to ceiling and secure with (x2) 1"L Phillips Flat Head Screw (B).
- 6. Carefully inspect the chandelier's fixture wires. White Color is the NEUTRAL WIRE. Black Color is the HOT WIRE. Green Color is the GROUND WIRE.
- 7. Connect the GROUND WIRE from the fixture with the ground wire (usually bare) from your ceiling box using a wire nut. If your house does not have ground wire, then attach the GROUND WIRE from the fixture to the green grounding screw inside of the outlet box. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
- 8. Connect the NEUTRAL WIRE from your fixture with the neutral wire (usually white) from your ceiling box using a wire nut.
- 9. Connect the HOT WIRE from your fixture with the hot wire (usually black) from your outlet box using a wire nut. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS; OTHERWISE, SAFETY WILL BE COMPROMISED.
- 10. Tuck the wire connection neatly into the ceiling outlet box.
- 11. Attach Canopy (C) with light fixture to affixed Mounting Plate (A) and secure with (x3) 3/16"L Hex Socket Set-screw (D).
- 12. Secure two Hook Bars (N) on Threaded Head (L) with (x4) M3 1/4"L Phillips Flat Head Screws (M).
- 13. Hold the Glass Shade (K) Carefully & take the Last Hook Bar (J) together; put them on seat & Hold the Last Hook Bar Carefully; secure the Last Hook Bar on Threaded Head with (x2) M3 1/4"L Phillips Flat Head Screws (I).
- 14. Insert the recommended bulb (P) into socket.
- 15. Assembly is complete.

CARE INSTRUCTIONS:

Wipe all surfaces with a soft dry cloth. Clean glass with a mild soap and water mixture. Do not use any harsh cleaners (including ammonia-based products) or abrasives, as they will damage the finish.