


PARTS ENCLOSED:

- (A) Mounting plugs (2)
- (B) Screws (2)
- (C) Wall plate (1)
- (D) Screws (2)
- (E) Lamp frame (1)
- (F) Nuts (2)
- (G)Glass (5)
- (H) Nuts (10)





IMPORTANT PLEASE READ

IMPORTANT INSTRUCTION:

- (1) Use an authorized and certified electrician for consultation and installation. Electrician must be familiar with commercial-type application of very wall lamp and hazards involved. Electrician should install it as per applicable installation code.
- (2) This fixture has been rated for 2x40-watt maximum E12,type B bulb.
- (3) To avoid the risk of fire, do not exceed the recommended wattage.
- (4) The manufacturer and distributor accept no liability for incorrect installation.
- (5) For indoor use only.
- (6) Keep away from children.

WARNINGS:

- (1) Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your wall lamp is fully assembled and installed.
- (2) All wires are connected. Do not remove the wall lamp from its packaging by pulling on the power cord, as a bad connection may result.
- (3) To reduce the risk of fire, electrical shock, or personal injury, always turn off the light and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- (4) Deviation from instruction may result in a risk of fire or electric shock.

THIS IS NOT A TOY. THE PRODUCT HAS NO PLAY VALUE.

ASSEMBLY & INSTALLATION:

- (1) Carefully remove the parts from the carton and place them on a flat surface. Please make sure that you have all the parts indicated before you begin to assemble this item.
- (2) Fix the wall plate (C) to the wall by using wall mounting plugs (A) and screws (B and D) to your wall type.
- (3) Connect the 3 power wires. The black wire is the live wire. The white wire is the neutral wire, and the brass wire is the earth wire.
- (4) Place the lamp frame (E) over the wall plate and fix it securely with the nuts (F) supplied.
- (5) Install 2pcs 40-Watt maximum Type B Candelabra incandescent lightbulb into the socket of the fixture. DO NOT EXCEED THE SPECIFIED WATTAGE.
- (6) Install 2pcs decoration glass (G) back to the lamp frame with the nuts (H).

CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp.

Wipe clean with a soft cloth.