









RESTORATION HARDWARE

MONTAUK BELL PENDANT 24"

PARTS:

ITEM	DIAGRAM	DESCRIPTION	QTY.
(A)		MOUNTING PLATE	1
(B)		THREADED TUBE	1
(C)		MOUNTING SCREW	2
(D)		EARTHING SCREW	1
(E)		CONNECTOR	3
(F)		CANOPY+METAL WIRE NUT	1
(G)		METAL WIRE	1
(H)		BULB (not included)	1

IMPORTANT SAFETY INSTRUCTIONS:

We recommend installation by a licensed electrician. This fixture has been rated for (1) 40-watt maximum Type A bulb. To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb. Do not touch bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE.



WARNING: STRANGULATION HAZARD

Keep cord at least 3 ft away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3.

TO ASSEMBLE:

- Carefully remove all parts from the box and remove all plastic covering.
- Turn off power to the junction box where the fixture will be installed.
- Insert threaded tube (B) halfway into mounting plate (A) and attach mounting plate (A) to ceiling outlet box using mounting screws (C).
- Pull wire from ceiling outlet box, and attach ground wire (usually green or bare wire) from ceiling box to ground wire on fixture with a plastic wire connector. Wrap this connection with electrical tape.
- Attach hot wire from ceiling box (usually black or smooth) with hot wire on fixture with a plastic wire connector, and wrap this connection with electrical tape.
- Attach neutral wire from ceiling box (usually white or ribbed) with neutral wire on fixture with a plastic wire connector, and wrap this connection with electrical tape.
- Slide canopy (F) up and hold flush against ceiling. Screw the metal wire nut (F) onto the threaded tube (B) to hang the fixture.
- Insert Type A bulb. (Not included)
- Restore power to the junction box and test fixture.
- Installation is complete.

CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp. Just wipe clean with soft cloth.

