


RH

ACANTHUS SCROLL TASK TABLE LAMP

PARTS ENCLOSED

(A) ACANTHUS SCROLL DESK LAMP (1)



IMPORTANT PLEASE READ**WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN****SAFETY INSTRUCTIONS:**

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for two (2) 5-watt maximum candelabra bulbs / CFL bulbs. To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result. Do not connect electricity until your lamp is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing the lightbulb. Do not touch the bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.

 **WARNINGS: STRANGULATION HAZARD**

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3 years of age.

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic coverings.
2. Insert the recommended bulb (not included) into the threaded socket.
3. Plug into proper electrical outlet and test fixture.
4. Assembly is complete.

CARE INSTRUCTIONS:

Do not use or clean with agents, solutions, or harsh chemicals. Wipe clean with a soft, dry cloth.
