










RESTORATIONHARDWARE

FOUCAULT'S ORB CRYSTAL CHANDELIER 14"

PARTS ENCLOSED

ITEMS	DIAGRAM	DESCRIPTION	QTY.
(A)		JunctionBox (Notincluded) 50LB.MIN.FIXTURERATED	1
(B)		CeilingHook	1
(C)		MountingScrews (Notincluded)	2Sets
(D1)		Canopy	1
(D2)			
(E1)		Collar	1
(E2)		HangStraight	
(E3)		Chain	
(E4)		Quicklink	
(F)		WireNut	3
(G)		CandleSleeve	3
(H)		Bulb+Spare	3+1
(I)		Body	1

IMPORTANT SAFETY INSTRUCTIONS:

- 1.Use an authorized and certified electrician for consultation and installation.
- 2.This fixture has been rated for 3x25-watt maximum E12standard bulb.
- 3.To avoid the risk of fire,donot exceed the recommended wattage.
- 4.The ceiling must have at least the capacity of 5times the weight of the ceiling light.
For this light at least a ceiling capacity of 16kg (35.27lb) is required.
- 5.The manufacturer and distributor accepts no liability for incorrect installation.
- 6.For indoor use only.
- 7.Keep away from children.

Warnings:


- 1.Turn-off electricity supply at main circuit panel before installing.Donot connect electricity supply until your ceilinglight is fully assembled and installed.
- 2.All wires are connected.Donot remove the ceiling light from its packaging by pulling on the powercord,as a bad connection may result.
- 3.To reduce the risk of fire,electrical shock,or personal injury,always turn off the ceiling light and allow it to cool prior to replacing lightbulb.Donot touch bulb when fixture is turned on or look directly at lightbulb.Keep flammable materials away from lightbulb.
- 4.Deviation from instructions may result in a risk of fire or electric shock.








PRODUCT DESCRIPTION:

General material: Chinese Crystal & Iron
Height:38.0cm (1 4.96in)
Diameter:35.5cm (13.78in)
Weight:3.2kg (7.05lb)
GroundedHardwired

TO ASSEMBLE:

- 1.Carefully remove all parts from the box and remove all plastic covering.
- 2.Turn OFF power to the junction box where the ceiling light will be installed.
- 3.Loosen the bolt of hang straight(E2)and remove the collar(E1)from the hangstraight (E2) by unscrewing it.Then insert collar(E1) into canopy (D1) and re-attach collar (E1) to hang straight (E2).Tighten the bolt of the hangstraight (E2).
- 4.Unlock the quick link (E4) at the opposite end of the chain (E3).
- 5.Attach the ceilinghook (B) to the ceiling with mounting screws (C).
- 6.Attach end of the collar (E1) to the ceilinghook (B).
- 7.Connect the ground wire from the fixture to the ground junction box wire(A) (Usually the green or bare wire) and wrap the connection with electrical tape.Connect the hot wire to the hot junction box wire (A)(Usually black or smooth)with a plastic wire nut (F) and wrap the connection with electrical tape.Connect the neutral wire to the neutral junction box wire (A) (Usually white or ribbed) with a plastic wire nut (F) and wrap the connection with electrical tape.
- 8.Move the canopy (D1) up to the ceiling, then fasten the bolt (D2).
- 9.Position glass dishes (7)and candle sleeves (G), and hang the crystals as per drawing on left.
- 10.Fasten light bulbs (H)to the lampholders.
- 11.Restore power to the junction box and test ceiling light fixture.



1 14mm*6PCS  3PCS	2 14mm*5PCS  6PCS	3 14mm*7PCS  3PCS	4 14mm*1PCS  38*26mm 3PCS	5  38*26mm 15PCS	6 14mm*1PCS  D30mm 1PCS	7  ø65*16mm 3PCS
---	---	---	--	--	--	--

CARE INSTRUCTIONS:

- 1.Make sure that the power is turned off and bulb has cooled before handling.
- 2.Wipe clean with a dry cloth mild soapy solution.Donot use corrosive cleaners.
- 3.The cable cord of this ceiling light cannot be replaced: If the cable is damaged,do not use the light.

ENVIRONMENT:

Special waste handling maybe required.Please contact your local authorities for more information.