


RESTORATION HARDWARE

Thank you for purchasing Restoration Hardware Lighting.
Our assortment is crafted with the highest quality details in mind.

PARTS ENCLOSED

- (A) Hanger Bar (1)
- (B) Hook (1)
- (C) Nut (1)
- (D) Shade (1)
- (E) Shade Ring (1)
- (F) Handle (1)
- (G) Lamp (1)

CARTESIAN SINGLE PULLEY PENDANT



IMPORTANT SAFETY INSTRUCTIONS:

This fixture has been rated for one (1) 40-watt maximum TYPE A standard bulb (not-included). To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result. Do not connect electricity until your lamp is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

TO ASSEMBLE:

(Professional Installation Recommended)

1. Remove lamp and shade from box, carefully unwrap
2. Screw hook into hanger bar, attach nut to the top side of the hook
3. Firmly attach hanger bar to your junction box
4. Place the light on the hook and attach the wires
5. Slide canopy towards ceiling and tighten the screws on the canopy ring
6. Unscrew socket ring. Slide shade over the socket then place the handle over the socket underneath the shade
7. Screw shade ring onto socket, holding the handle and shade in place

CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp.
JUST WIPE CLEAN WITH A SOFT, DRY CLOTH.