

RESTORATION HARDWARE

BISTRO GLOBE 16 LIGHT CHANDELIER

PARTS ENCLOSED

- | | |
|-------------------------|--------------------------|
| (A) Mounting Plate | (K) Connective Tubes (5) |
| (B) Mounting Screws (2) | (L) Light fixture |
| (C) Canopy (1) | (M) Thumbscrews (64) |
| (D) Mounting Loop | (N) Shade Holders (16) |
| (E) Canopy Screws (3) | (O) Glass Shades (16) |
| (F) Hanging Loop | (P) Light Bulbs (16) |
| (G) 18" Rods (2) | |
| (H) 12" Rods (2) | |
| (J) 6" Rods (2) | |

IMPORTANT SAFETY INSTRUCTIONS

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.

This fixture has been rated for up to sixteen (16) 40-watt maximum Type G-16.5 bulbs (O) (included) or sixteen (16) 9-watt compact fluorescent light bulbs (not included). To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS

1. All wires are connected.
2. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
3. Do not connect electricity until your lamp is fully assembled.
4. To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb.
5. Do not touch bulb when fixture is turned on or look directly at lit bulb.
6. Keep flammable materials away from lit bulb.
7. This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

TO ASSEMBLE

1. Carefully remove all parts from the box and remove all plastic covering.
2. Determine the hanging length of pendant. Connect Light Fixture (L) to some or all Connection Rods (G) (H) (J) and Connective Tubes (K) according to the height needed.
3. Thread Hanging Loop (F) onto the inner connection rod of the top cord cover.
4. Hook Hanging Loop (F) to mounting loop (D).
5. Remove Mounting Plate (A) from Canopy (C) by removing Canopy Screws (E).
6. Place Mounting Plate (A) to ceiling outlet box with Mounting Screws (B)
7. Feed wires through the Connection Rods, Hanging Loop (F) Mounting Loop (D) and Canopy (C).
8. Attach the fixture ground wire (green) to the ground wire from the outlet box (usually green insulation or bare wire) with a plastic wire connector and wrap the connection with electrical tape.
9. Connect the neutral wire (white) to the neutral outlet wire (usually white insulation) with a plastic wire connector and wrap the connection with electrical tape.
10. Connect the hot wire (black) to the hot outlet box wire (usually black insulation) with a plastic wire connector and wrap the connection with electrical tape. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
11. Tuck the wire connection neatly into the ceiling outlet box.
12. Attach Canopy (C) with light fixture to affixed Mounting Plate (A) and secure with Canopy Screws (E).
13. Insert the recommended bulbs (O) into sockets.
14. Loosen Thumbscrews (M), attach Glass Shades (O) to Shade Holders (N) and tighten with Thumbscrews (M). DO NOT OVER TIGHTEN OTHERWISE GALL WILL BE DAMAGE.
15. Assembly is complete.

CARE INSTRUCTIONS

Wipe all surfaces with a soft dry cloth. Clean glass with a mild soap and water mixture. Do not use any harsh cleaners (including ammonia-based products) or abrasives, as they will damage the finish.

