
RESTORATION HARDWARE

FONTANELLE FLOOR LAMP

PARTS ENCLOSED:

- (A) Base (1)
- (B) Tube (1)
- (C) Weight (4)
- (D) Arm hole (4)
- (E) Bulb (4)
- (F) Glass tube (4)
- (G) Allen key (1)
- (H) Center box (1)



IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (4) 40-watt maximum TYPE T8 bulbs. To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off lamp and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

TO ASSEMBLE:

- 1. Carefully remove all parts from the box and remove all plastic covering.
- 2. Put the Tube (B) onto the Base (A) and turn clockwise until the Tube (B) screw into the Base (A). Secure Tube (B) by using Allen key (G) provided.
- 3. Put the Tube (B) onto the Center box(H) and turn clockwise until the Tube (B) screw into the Center box (H). Secure Tube (B) by using Allen key (G) provided.
- 4. Insert the 40-watt Type T8 bulbs (included) into threaded sockets. And put the Glass tubes(F) to cover the bulbs.
- 5. Insert the Weights(C) Into the Arm holes(D) and turn clockwise until the Weights(C) screw into the Arm holes(D), and tighten it.
- 6. Plug into proper electrical outlet and test fixture.
- 7. Assembly is complete.

CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp. JUST WIPE CLEAN WITH SOFT CLOTH.