RH

PARTS ENCLOSED:


(A) Finial (1)

(B) Harp (1)

(C) Saddle (2)

(D) Polarized Plug (1)

(E) 9-watt LED Lightbulb (1)



IMPORTANT PLEASE READ

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.

SAFETY INSTRUCTIONS:

These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.

This lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into the outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to one (1) 100-watt maximum Type A medium base bulb or one (1) 9-watt LED medium base bulb (included). To avoid risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your fixture is fully assembled. To reduce the risk of fire, electrical shock or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb. Do not touch bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from the lit bulb.

This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning, or otherwise touching this light fixture.

WARNING: This product can expose you to lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE.

WARNING: STRANGULATION HAZARD Keep cord at least 3 ft away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3.

ASSEMBLY & INSTALLATION:

NOTE: Do not connect the electricity until lamp is fully assembled.

- 1. Remove all parts carefully from the carton. Do not throw away any parts.
- 2. Remove all packaging material from lamp.
- 3. Remove finial (A) from top of harp (B). Squeeze harp (B) inward and place into the opening of saddle (C).
- 4. Install one (1) 9-watt maximum Type A LED medium base bulb (E) (included) into socket.
- 5. Place shade (not included) onto harp (B).
- 6. Thread finial (A) onto harp (B) to secure shade to lamp.
- 7. Remove plug cover from polarized plug (D).
- 8. Insert polarized plug (D) into wall outlet.
- 9. Control power to the lamp using turn knob on socket.

CARE INSTRUCTIONS:

Wipe clean with a soft, dry cloth or static duster. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.