


# RH

## MÉTIER DOME SHADE TASK TABLE LAMP

### PARTS ENCLOSED

- (A) Threaded Collar (1)
- (B) Inner Pole (1)
- (C) Allen Wrench (1)
- (D) Set Screw (1)
- (E) Bulb (1)



## MÉTIER DOME SHADE TASK TABLE LAMP

**IMPORTANT SAFETY INSTRUCTIONS**

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for one (1) 35-Watt maximum Halogen Bulb (E) (included). To avoid the risk of fire, do not exceed the recommended wattage.

**WARNINGS**

All wires are connected. When unpacking, be careful not to pull wires, as a bad connection may result. Do not connect electricity until your fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the light bulb. Do not touch or look directly at the bulb when fixture is illuminated. Keep flammable materials away from lit bulb.



**WARNING:** This product can expose you to lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

**THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE.**



**WARNING: STRANGULATION HAZARD**

Keep cord at least 3 ft away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3.

**ASSEMBLY & INSTALLATION**

1. Carefully remove all parts from the box and remove all plastic covering.
2. Check the Set Screw (D) using Allen Wrench (C) provided. Tighten the Set Screw (D) with Allen Wrench (C) if it is loose.
3. Insert Bulb (E) into the socket.
4. Plug into proper electrical outlet and test fixture.
5. Assembly is complete.

**HEIGHT ADJUSTMENT**

1. Loosen Threaded Collar (A) in the counter-clockwise direction.
2. Adjust lamp by pulling or pushing Inner Pole (B) up or down to the desired height.
3. Tighten Threaded Collar (A) in the clockwise direction.

**CARE INSTRUCTIONS**

Do not use polishes or cleaners on your lamp. Just wipe clean with a soft cloth.