

RESTORATION HARDWARE

FONTANELLE ROUND 58 INCH CHANDELIER

PARTS ENCLOSED: HARDWARE INCLUDED:

- | | |
|------------------------|--------------------------------|
| (A) Fixture stud (1) | (a) Plastic wire connector (3) |
| (B) Swivel (1) | (b) Toggle (4) |
| (C) Canopy (1) | (c) Screw (4) |
| (D) Ring (1) | (d) Allen key (1) |
| (E) Base (1) | |
| (F) Tube (1) | |
| (G) Center box (1) | |
| (H) Extension tube (8) | |
| (I) Bulb (16) | |
| (J) Glass tube (16) | |
| (K) Weight (16) | |
| (L) Arm hole (16) | |

IMPORTANT SAFETY INSTRUCTIONS:

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.
This fixture has been rated for up to (16) 25-watt maximum TYPE T8 bulbs.
To avoid the risk of fire, do not exceed the recommended wattage.
A mechanical dimmer switch can match this lamp .

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off lamp and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.
Keep flammable materials away from lit bulb.

This lighting fixture contains lead, a chemical know to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

TO ASSEMBLE:

- Carefully remove all parts from the box and remove all plastic covering.
- Shut of electrical supply at main fuse box / circuit breaker. A licensed electrician should install this fixture.
- Put the Tube(F) onto the Center box(G) and turn clockwise until the Tube(F) screw into the Center box(G). Secure Tube (F) by using Allen key (d) provided.
- Put the Tube(F) onto the Swivel(B) and turn clockwise until the Tube(F) screw into the Swivel(B). Secure the Tube (F) by using Allen key (d) provided.
- If need, disassemble the existing suspension tube by unscrewing the sections apart. Pull the wire back through the Swivel section that will be need to be extended. Locate the Extension tubes(H) and check the actual suspension length conditions to the incremental fixture suspension length per number of extensions desired.
- Attach the ground wire from the fixture to the ground junction box wire from the outlet box (Usually green or bare wire) with a plastic wire connector(a) and wrap the connection with electrical tape.
- Connect the hot wire to the hot junction box wire (usually black or smooth) with a plastic wire connector(a) and wrap the connection with electrical tape. Connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a plastic wire connector(a) and wrap the connection with electrical tape.
- Attach Fixture stud (A) to ceiling beam through outlet box . Have professional contractor reinforce ceiling.
- Attach the Canopy (C) to the Fixture stup (A) using the Ring (D) and tighten it.
- Insert the 25-watt Type T8 bulbs (included) into threaded sockets. And put the Glass tubes(J) to cover the bulbs.
- Insert the Weights(K) Into the Arm holes(L) and turn clockwise until the Weights(K) screw into the Arm holes(L). and tighten it.
- Restore power to the junction box and test lamp fixture.
- Installation is complete.

CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp.
JUST WIPE CLEAN WITH SOFT CLOTH.

