




JUNEAU FLOOR LAMP

ASSEMBLY & INSTALLATION INSTRUCTIONS

ENGLISH

PARTS INCLUDED

- (A) Finial (1)
- (B) Harp (1)
- (C) Saddle (1)
- (D) Polarized Plug (1)
- (E) 9-watt LED Bulb (1)



IMPORTANT: PLEASE READ

PLEASE FOLLOW THE ASSEMBLY INSTRUCTIONS CLOSELY. IMPROPER ASSEMBLY OR INSTALLATION CAN RESULT IN PERSONAL OR PROPERTY DAMAGE. IF YOU ARE UNSURE ABOUT YOUR WALL TYPE OR WHAT MOUNTING METHOD YOU SHOULD USE, CONSULT A QUALIFIED PROFESSIONAL OR YOUR LOCAL HARDWARE STORE.

INSTALLATION BY A LICENSED ELECTRICIAN IS STRONGLY RECOMMENDED.

IMPORTANT SAFETY FEATURES**BULBS**

This lamp has been rated for one (1) 100-watt maximum Type A incandescent lightbulb or one (1) 9-watt maximum LED lightbulb (included). To avoid the risk of fire, do not exceed the recommended wattage.

DIMMER SWITCH COMPATIBILITY

This lamp is dimmer-switch compatible and may only be used with a mechanical dimmer switch.

WARNINGS

All wires are connected. When unpacking, be careful not to pull wires, as damage may result. Do not connect electricity until the lamp is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off lamp and allow it to cool prior to replacing the lightbulb. Do not touch or look directly at the bulb when lamp is illuminated. Keep flammable materials away from lit bulb.

If the external flexible cable or cord of this lamp is damaged, it shall be exclusively replaced by the manufacturer, their service agent, or a similarly qualified person in order to avoid a hazard.

WARNING STRANGULATION HAZARD

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3 years of age.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.

ASSEMBLY AND INSTALLATION**SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE FUSE BOX OR CIRCUIT BREAKER PANEL.**

NOTE: Do not connect the electricity until lamp is fully assembled.

1. Remove all parts carefully from the carton. Do not throw away any parts.
2. Remove all packaging material from lamp.
3. Remove finial (A) from top of harp (B). Squeeze harp (B) inward and place it into the opening of saddle (C).
4. Screw one (1) 9-watt maximum LED bulb (E) (included) into socket.
5. Place shade (not included) onto harp (B).
6. Thread finial (A) onto harp (B) to secure shade to lamp.
7. Remove plug cover from polarized plug (D).
8. Insert polarized plug (D) into wall outlet.
9. Turn on power and test the lamp by turning it on.
10. Assembly is complete.

CARE INSTRUCTIONS

Do not use polishes or cleaners on the lamp.

Wipe clean with a soft, dry cloth.