

RH


QUINTON TASK FLOOR LAMP

ASSEMBLY & INSTALLATION INSTRUCTIONS

UNITED STATES ENGLISH

RH

QUINTON TASK FLOOR LAMP



QUINTON TASK FLOOR LAMP

IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock.

This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

This lamp has been rated for one (1) 10-watt integrated LED energy-saving bulb (included). To avoid the risk of fire, do not exceed the recommended wattage.

WARNING

All wires are connected. When unpacking, be careful not to pull wires, as a bad connection may result. Do not connect electricity until your lamp is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off lamp and allow it to cool prior to replacing the lightbulb. Do not touch or look directly at the bulb when lamp is illuminated. Keep flammable materials away from lit bulb.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.



WARNING: STRANGULATION HAZARD

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds.

Keep out of reach of children under 3 years of age.

ASSEMBLY & INSTALLATION

1. Carefully remove all parts from the box and remove all plastic coverings.
2. Plug into proper electrical outlet and test **lamp**.
3. Assembly is complete.

CAUTION:

Do not move the lamp by grabbing only the lamp body. To keep the heavy base from falling to the ground, move the lamp by holding both the body and the base.

REMINDER:

The LED bulb is replaceable. Please check with the RH service center for more information.

CARE INSTRUCTIONS

Wipe all surfaces with a soft, dry cloth. Do not use any harsh cleaners (including ammonia-based products) or abrasives on your lamp, as they will damage the finish.