


T-BASE TASK FLOOR LAMP

PARTS ENCLOSED

- (A) Threaded Collar
- (B) Inner Pole
- (C) Bulb (1)
- (D) Socket
- (E) Dimmer Switch



IMPORTANT SAFETY INSTRUCTIONS

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into outlet, do not force it-contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for one (1) 4-Watt Type G9 Dimmable LED lightbulb (included). To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS

All wires are connected. When unpacking, be careful not to pull wires, as a bad connection may result. Do not connect electricity until your fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb. Do not touch or look directly at the bulb when fixture is illuminated. Keep flammable materials away from lit bulb.



WARNING: This product can expose you to lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.



WARNING: STRANGULATION HAZARD

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3 years of age.

ASSEMBLY & INSTALLATION

1. Carefully remove all parts from the box and remove all plastic coverings.
2. Insert Bulb (C) into Socket (D) by pushing in.
3. Plug into proper electrical outlet and test fixture.
4. Push the button on Dimmer Switch (E) to desired luminance.
5. Assembly is complete.

HEIGHT ADJUSTMENT

1. Loosen Threaded Collar (A) in a counterclockwise direction.
2. Adjust lamp by pulling or pushing Inner Pole (B) up or down to desired height.
3. Tighten the Threaded Collar (A) in a clockwise direction.

CARE INSTRUCTIONS

Wipe all surfaces with a soft, dry cloth. Do not use any harsh cleaners (including ammonia-based products) or abrasives on your lamp, as they will damage the finish.