



CHARACTERISTICS

Our Indonesian teak originates from forests regulated by Indonesia's Sustainable Forest Management (SFM/ PHPL) and Verification of Timber Legality (TLAS/SVLK) systems, designed to promote the sustainability of future teak harvests while ensuring legal trade.

Teak is dense and has a high oil content, which makes it particularly suitable for outdoor use. The natural oils prevent rotting and provide resistance to fungus, termites and wood-boring pests.

RH's Weathered Teak finish is hand applied to our teak frames using a wire brush to distress the wood before applying a multilayered painted finish, achieving a weathered look.

Teak expands and contracts with changes in climate. Shrinking of the wood can result in hairline cracks in the assembly joints or the grain of the wood itself. This does not affect the structural integrity of the frame's construction.

Moisture contributes to the natural expansion and contraction of both the teak and the painted finish, which can result in hairline cracks in the finish.

As with any painted finish, our Weathered Teak finish will fade and wear with exposure to the elements. As the finish flakes off, the natural teak underneath will become exposed and start to turn grey. The rate at which the finish weathers will vary depending upon climate, exposure and commitment to care and maintenance. This weathering process is accelerated when furniture is left untreated or uncovered.


We strongly recommend using our custom-fit outdoor covers to protect furniture from the elements and minimize aging.



WEATHERED TEAK FINISH
(NEW)



WEATHERED TEAK FINISH
(WITH SOME MAINTENANCE)



WEATHERED TEAK FINISH
(WITH NO MAINTENANCE)

CARE & MAINTENANCE

Once the weathering of the finish begins, we recommend the following:

- Hose down the furniture (DO NOT use a power washer) and clean with Golden Care® Hardwood & Teak Cleaner using a sponge or soft scrub brush to remove dirt and loose paint, ensuring a clean surface. Allow the surface to dry for 24 hours.
- If exposure to moisture over time has raised the wood grain, sand lightly with 120-grit sandpaper.
- Apply Golden Care® Instant Grey to maintain the color of your finish. Allow to air dry for 24 hours.
- Apply Golden Care® Hardwood & Teak Shield to protect from UV rays, mold and mildew, and food and drink stains.

RECOMMENDATIONS

- Avoid letting water stand on the surface of furniture and cushions.
- Do not allow wet cushions to sit on a frame for extended periods of time, as trapped moisture will contribute to the deterioration of the finish.
- As with all RH Outdoor purchases, we recommend using our custom furniture covers for teak items when not in use; furniture cushions and covers should be clean and dry before covering.
- Cushions should be removed - whenever possible - before covering the frames for longer than a few days to avoid mold and mildew build-up.
- If cushions get wet, tip them on their sides with the zipper facing down and unzipped to ensure that all water drains.