

LAUREL TEAK SEATING COLLECTION







All dimensions are given in inches. See the attached "Dimensions Diagram" sheet for more information on the keys used in this chart.

	OVERALL WIDTH A	OVERALL DEPTH B	OVERALL HEIGHT W/ CUSHION C	FRAME HEIGHT D	ARM HEIGHT E	ARM WIDTH F	FOOT HEIGHT G	SEAT HEIGHT W/ CUSHION H	SEAT HEIGHT (FLOOR TO FRAME) I	INSIDE SEAT WIDTH J	INSIDE SEAT DEPTH K	# OF BACK CUSHIONS	# OF SEAT CUSHIONS	WEIGHT
60" SOFA	60	33	31½	26½	26½	1¾	9¾	18	11½	54	30¾	2	1	
72" SOFA	72	33	31½	26½	26½	1¾	9¾	18	11½	66	30¾	2	1	
84" SOFA	84	33	31½	26½	26½	1¾	9¾	18	11½	78	30¾	2	1	
96" SOFA	96	33	31½	26½	26½	1¾	9¾	18	11½	90	30¾	2	1	
108" SOFA	108	33	31½	26½	26½	1¾	9¾	18	11½	102	30¾	2	1	
LOUNGE CHAIR	33	33	31½	26½	26½	1¾	9¾	18	11½	26¾	30¾	1	1	
OTTOMAN	30	22	18	11½	-	-	9¾	18	11½	30	22	0	1	
CHAISE	29¾	80¾	37	10	-	-	7¾	14	10	29¾	49	1	1	
DINING ARMCHAIR	24¾	24¾	32	31	17	1½	15	20½	17	19	21½	1	1	
DINING SIDE CHAIR	22	24¾	32	31	-	-	15	20½	17	19	21½	1	1	

OUTDOOR SEATING DIMENSIONS DIAGRAM

See the "Dimensions Sheet" for the measurements that correspond with the letters below.

RH



OUTDOOR SEATING DIMENSIONS DIAGRAM

See the "Dimensions Sheet" for the measurements that correspond with the letters below.

RH

