BLAKE MOTION COLLECTION


All dimensions are given in inches. See the attached "Dimensions Diagram" sheet for more information on the keys used in this chart.





	OVERALL DIMENSIONS				MOTION					SEAT				ARM			FOOT	CUSHIONS		
	▶ OVERALL WIDTH	₪ OVERALL DEPTH	O OVERALL HEIGHT	☐ FRAME HEIGHT	□ FULLY RECLINED DEPTH	RECLINING CLEARANCE NEEDED (BACK OF ARM)	© RECLINING CLEARANCE NEEDED (FRONT OF ARM)	国 FULLY RECLINED BACK HEIGHT	FULLY RAISED FOOTREST HEIGHT	SEAT DEPTH	INSIDE SEAT WIDTH	□ SEAT HEIGHT	INSIDE BACK HEIGHT TO TOP OF SEAT	Z ARM WIDTH	O ARM HEIGHT	TOP OF ARM TO TOP OF SEAT	D FOOT HEIGHT	NUMBER OF BACK CUSHIONS	NUMBER OF SEAT CUSHIONS	NUMBER OF ACCENT PILLOWS
RECLINER	45	45	31½	26½	67½	41/4	18¼	36½	21¾	25¼	26	19	12½	9½	25¾	7	2	1	1	-
MODULAR LEFT-ARM MOTION CHAIR	491/4	461/4	31½	26½	67½	41/4	18¼	36½	231/4	26½	35¾	19	121/2	13½	25¾	7	2	1	1	-
MODULAR RIGHT-ARM MOTION CHAIR	49¼	46¼	31½	26½	67½	41/4	18¼	36½	23¼	26½	35¾	19	12½	13½	25¾	7	2	1	1	-
MODULAR ARMLESS MOTION CHAIR	36½	46¼	31½	26½	67½	41/4	18¼	36½	23¼	26½	36½	19	12½	-	-	7	2	1	1	-
54%" MODULAR STATIONARY CORNER CHAIR	54¾	54¾	31½	26½	-	-	-	-	-	35¼	51¼	19	12½	-	-	7	2	1	1	-
62½" MODULAR STATIONARY CORNER CHAIR	62½	62½	31½	26½	-	-	-	-	-	43	62¼	19	12½	-	-	7	2	1	1	-

DIMENSIONS SHEET (10-23-24)










DIMENSIONS DIAGRAM (10-23-24)




54¾" CORNER CHAIR



The 54%" Corner Chair allows space for one footrest on adjacent reclining chair to be fully raised.

Footrests on both adjacent reclining chairs can be raised at the same time at lower angles.


62½" CORNER CHAIR




The 62½" Corner Chair allows space for reclining chair on either side to extend fully with both footrests raised.

DIMENSIONS DIAGRAM (10-23-24)






The motion controller buttons on an armless reclining chair will not be visible when placed next to another sectional component.



To operate the motion controller, reach down the right-hand side of the armless reclining chair.

Buttons are located in the middle of the seat, 6" below the side seam.



Button 1 reclines backrest and raises footrest.

Button 2 closes footrest, backrest and headrest.

Button 3 elevates headrest.

Button 4 closes headrest.


DIMENSIONS DIAGRAM (10-23-24)

BLAKE MOTION COLLECTION - WITH 54¾" CORNER


MODULAR SECTIONAL

RH


MODULAR 2-PIECE SOFA




MODULAR 3-PIECE SOFA




MODULAR 4-PIECE SOFA



MODULAR 5-PIECE SOFA



MODULAR 6-PIECE SOFA




SECTIONAL DIAGRAMS (10-23-24) RH.COM | 800.762 1005

BLAKE MOTION COLLECTION - WITH 62½" CORNER


MODULAR SECTIONAL




MODULAR 2-PIECE SOFA




MODULAR 3-PIECE SOFA




MODULAR 4-PIECE SOFA



MODULAR 5-PIECE SOFA



MODULAR 6-PIECE SOFA



SECTIONAL DIAGRAMS (10-23-24) RH.COM | 800.762 1005