

LENNON RECLINER COLLECTION

All dimensions are given in inches. See the attached "Dimensions Diagram" sheet for more information on the keys used in this chart.




	OVERALL DIMENSIONS				RECLINER					SEAT				ARM			FOOT	CUSHIONS		
	OVERALL WIDTH A	OVERALL DEPTH B	OVERALL HEIGHT C	FRAME HEIGHT D	FULLY RECLINED DEPTH E	HEADREST CLEARANCE NEEDED F	FOOTREST CLEARANCE NEEDED G	FULLY RECLINED BACK HEIGHT H	FULLY RAISED FOOTREST HEIGHT I	INSIDE SEAT WIDTH J	INSIDE SEAT DEPTH K	SEAT HEIGHT L	INSIDE BACK HEIGHT TO TOP OF SEAT M	OVERALL ARM WIDTH N	ARM WIDTH SEAM TO SEAM O	OVERALL ARM HEIGHT P	FOOT HEIGHT Q	NUMBER OF BACK CUSHIONS	NUMBER OF SEAT CUSHIONS	NUMBER OF ACCENT PILLOWS
7' RECLINER SOFA	84	43	31½	31½	65½	4	20	40½	25	69	23	19½	12	7½	7	26	2	2	2	-
8' RECLINER SOFA	96	43	31½	31½	65½	4	20	40½	25	81	23	19½	12	7½	7	26	2	3	3	-
9' RECLINER SOFA	108	43	31½	31½	65½	4	20	40½	25	93	23	19½	12	7½	7	26	2	3	3	-
MODULAR RECLINER LEFT/ RIGHT ARM CHAIR	40½	43	31½	31½	65½	4	20	40½	25	33	23	19½	12	7½	7	26	2	1	1	-
MODULAR RECLINER ARMLESS CHAIR	33	43	31½	31½	65½	4	20	40½	25	33	23	19½	12	-	-	-	2	1	1	-
MODULAR STATIONARY ARMLESS CHAIR	33	43	31½	31½	-	-	-	-	-	33	23	19½	12	-	-	-	2	1	1	-
53" MODULAR STATIONARY CORNER WEDGE	53	53	31½	31½	-	-	-	-	-	44	39	19½	12	-	-	-	2	2	1	-
65" MODULAR STATIONARY CORNER WEDGE	65	65	31½	31½	-	-	-	-	-	62	49	19½	12	-	-	-	2	2	1	-
RECLINER	38	43	31½	31½	65½	4	20	40½	25	25	23	19½	12	6½	6	26	2	1	1	-

LENNON RECLINER DIMENSIONS DIAGRAM

See the "Dimensions Sheet" for the measurements that correspond with the letters below.

RH




LENNON RECLINER MODULAR L-SECTIONAL CORNER WEDGE CONFIGURATION

See the "Dimensions Sheet" for the measurements that correspond with the letters below.

RH


53" CORNER WEDGE



The 53" Corner Wedge allows space for one footrest on adjacent reclining chair to be fully raised.

Footrests on both adjacent reclining chairs can be raised at the same time at lower angles.

65" CORNER WEDGE




The 65" Corner Wedge allows space for reclining chair on either side to extend fully with both footrests raised.


LENNON RECLINER MODULAR ARMLESS RECLINER CHAIR BUTTON PLACEMENT

See the "Dimensions Sheet" for the measurements that correspond with the letters below.

RH




The motion controller buttons on an armless reclining chair will not be visible when placed next to another sectional component.



To operate the motion controller, reach down the right-hand side of the armless reclining chair.

Buttons are located in the middle of the seat, 3½" below the side seam.




Button 1 raises the footrest.


Button 2 elevates the headrest.

Button 3 opens and closes the backrest and footrest.


MODULAR 2 PIECE SOFA




MODULAR 3 PIECE SOFA




MODULAR 4 PIECE SOFA




MODULAR 5 PIECE SOFA




MODULAR 6 PIECE SOFA




MODULAR 2 PIECE SOFA




MODULAR 3 PIECE SOFA



MODULAR 4 PIECE SOFA



MODULAR 5 PIECE SOFA



MODULAR 6 PIECE SOFA

