# MONCEAU MOTION COLLECTION


All dimensions are given in inches. See the attached "Dimensions Diagram" sheet for more information on the keys used in this chart.





	OVERALL DIMENSIONS				MOTION					SEAT				ARM			FOOT	FOOT CUSHIONS			
	▼ OVERALL WIDTH	₪ OVERALL DEPTH	O OVERALL HEIGHT	D FRAME HEIGHT	☐ FULLY RECLINED DEPTH	RECLINING CLEARANCE  NEEDED (BACK OF ARM)	© RECLINING CLEARANCE NEEDED (FRONT OF ARM)	国 FULLY RECLINED 国 BACK HEIGHT	E FULLY RAISED FOOTREST HEIGHT	SEAT DEPTH	INSIDE SEAT WIDTH	□ SEAT HEIGHT	INSIDE BACK HEIGHT TO TOP OF SEAT	Z ARM WIDTH	O ARM HEIGHT	TOP OF SEAT	Б 600Т НЕІСНТ	NUMBER OF BACK CUSHIONS	NUMBER OF SEAT CUSHIONS	NUMBER OF ACCENT PILLOWS	
7' MOTION SOFA	84	43	32½	32½	64½	3	21½	25¼	23½	24	62	191/4	13¼	11	31	11¾	2	2	2	-	
8' MOTION SOFA	96	43	32½	32½	64½	3	21½	25¼	23½	24	74	19¼	131/4	11	31	11¾	2	2	2	-	
9' MOTION SOFA	108	43	32½	32½	64½	3	21½	25¼	23½	24	86	19¼	131/4	11	31	113/4	2	2	2	-	
RECLINER	43	43	32½	32½	64½	3	21½	25¼	23½	24	24	191/4	131/4	9½	31	113/4	2	1	1	-	
MODULAR LEFT-ARM MOTION CHAIR	43½	43	32½	32½	64½	3	21½	25¼	23½	24	32½	19¼	131/4	11	31	11¾	2	1	1	-	
MODULAR RIGHT-ARM MOTION CHAIR	43½	43	32½	32½	64½	3	21½	25¼	23½	24	32½	19¼	13¼	11	31	11¾	2	1	1	-	
MODULAR ARMLESS MOTION CHAIR	32½	41½	32½	32½	64½	3	21½	25¼	23½	24	32½	19¼	131/4	-	-	-	2	1	1	-	
MODULAR ARMLESS STATIONARY CHAIR	32½	41½	32½	32½	-	-	-	-	-	24	32½	19¼	13¼	-	-	-	2	1	1	-	
49½" MODULAR STATIONARY CORNER CHAIR	49½	49½	32½	32½	-	-	-	_	-	25¾	43	19¼	13¼	-	-	-	2	2	1	-	
65" MODULAR STATIONARY CORNER CHAIR	65	65	32½	32½	-	-	-	-	-	31½	66	19¼	13¼	-	-	-	2	2	1	-	

DIMENSIONS SHEET (11-11-24)










DIMENSIONS DIAGRAM (11-11-24)




## 49½" CORNER CHAIR



The 49½" Corner Chair allows space for one footrest on adjacent reclining chair to be fully raised.

Footrests on both adjacent reclining chairs can be raised at the same time at lower angles.


## 65" CORNER CHAIR




The 65" Corner Chair allows space for reclining chair on either side to extend fully with both footrests raised.

DIMENSIONS DIAGRAM (11-11-24)






The motion controller buttons on an armless reclining chair will not be visible when placed next to another sectional component.



To operate the motion controller, reach down the right-hand side of the armless reclining chair.

Buttons are located in the middle of the seat, 3½" below the side seam.




Button 1 raises the footrest.
Button 2 elevates the headrest.
Button 3 opens and closes the backrest and footrest.


DIMENSIONS DIAGRAM (11-11-24)




#### MODULAR 3 PIECE SOFA




# MODULAR 5 PIECE SOFA



## MODULAR 4 PIECE SOFA



## MODULAR 6 PIECE SOFA




SECTIONAL DIAGRAMS (11-11-24)


RH.COM | 800.762.1005




#### MODULAR 3 PIECE SOFA




## MODULAR 5 PIECE SOFA



## MODULAR 4 PIECE SOFA



## MODULAR 6 PIECE SOFA



SECTIONAL DIAGRAMS (11-11-24)

RH.COM | 800.762.1005