

YETI MOTION COLLECTION

All dimensions are given in inches. See the attached "Dimensions Diagram" sheet for more information on the keys used in this chart.




	OVERALL DIMENSIONS				MOTION					SEAT				ARM			FOOT	CUSHIONS		
	OVERALL WIDTH A	OVERALL DEPTH B	OVERALL HEIGHT C	FRAME HEIGHT D	FULLY RECLINED DEPTH E	RECLINING CLEARANCE NEEDED (BACK OF ARM) F	RECLINING CLEARANCE NEEDED (FRONT OF ARM) G	FULLY RECLINED BACK HEIGHT H	FULLY RAISED FOOTREST HEIGHT I	SEAT DEPTH J	INSIDE SEAT WIDTH K	SEAT HEIGHT L	INSIDE BACK HEIGHT TO TOP OF SEAT M	ARM WIDTH N	ARM HEIGHT O	TOP OF ARM TO TOP OF SEAT P	FOOT HEIGHT Q	NUMBER OF BACK CUSHIONS	NUMBER OF SEAT CUSHIONS	NUMBER OF ACCENT PILLOWS
ARMLESS RECLINER	36½	49	35	35	65¾	7	17	25½	23¾	27½	32	18½	16½	-	-	-	1¼	-	-	-
ARMLESS STATIONARY CHAIR	36½	49	35	35	-	-	-	-	-	27½	32	18½	16½	-	-	-	1¼	-	-	-
ARMLESS SWIVEL CHAIR	36½	49	35	35	-	-	-	-	-	27½	32	18½	16½	-	-	-	-	-	-	-
MODULAR ARMLESS MOTION CHAIR	36½	49	35	35	65¾	7	17	25½	23¾	27½	32	18½	16½	-	-	-	1¼	-	-	-
MODULAR ARMLESS STATIONARY CHAIR	36½	49	35	35	-	-	-	-	-	27½	32	18½	16½	-	-	-	1¼	-	-	-
54" MODULAR STATIONARY CORNER CHAIR	54	54	35	35	-	-	-	-	-	27½	54	18½	16½	-	-	-	1¼	-	-	-
59½" MODULAR STATIONARY CORNER CHAIR	59½	59½	35	35	-	-	-	-	-	27½	62	18½	16½	-	-	-	1¼	-	-	-

YETI MOTION DIMENSIONS DIAGRAM

See the "Dimensions Sheet" for the measurements that correspond with the letters below.

RH




YETI MOTION MODULAR L-SECTIONAL CORNER CHAIR CONFIGURATION

See the "Dimensions Sheet" for the measurements that correspond with the letters below.

RH


54" CORNER CHAIR



The 54" Corner Chair allows space for one footrest on adjacent reclining chair to be fully raised.

Footrests on both adjacent reclining chairs can be raised at the same time at lower angles.

59½" CORNER CHAIR




The 59½" Corner Chair allows space for reclining chair on either side to extend fully with both footrests raised.


YETI MOTION MODULAR ARMLESS RECLINER CHAIR BUTTON PLACEMENT

See the "Dimensions Sheet" for the measurements that correspond with the letters below.

RH




The motion controller buttons on an armless reclining chair will not be visible when placed next to another sectional component.




To operate the motion controller, reach down the right-hand side of the armless reclining chair.

Buttons are located in the middle of the seat, 6" below the side seam.




Button 1 reclines backrest and raises footrest.
Button 2 closes footrest, backrest and headrest.


MODULAR 3-PIECE SOFA




MODULAR 4-PIECE SOFA




MODULAR 5-PIECE SOFA




MODULAR 6-PIECE SOFA




MODULAR 3-PIECE SOFA



MODULAR 4-PIECE SOFA



MODULAR 5-PIECE SOFA



MODULAR 6-PIECE SOFA

