RH

VINTAGE ITALIAN TANNERY OAK DINING TABLE INSTRUCTIONS


PARTS INCLUDED

A [1] TABLETOP

B [2] LEGS

C [1] STRETCHER

D [2] EXTENSIONS



HARDWARE INCLUDED

NO.	ITEM	DESCRIPTION	QTY.
1	•	Allen Bolt 5/16" x 1½"	12 pcs.
2	0	Lock Washer	14 pcs.
3	0	Flat Washer	14 pcs.
4		Allen Wrench	1 pc.
5	•	Allen Bolt 5/16" x 2"	2 pcs.

ASSEMBLY INSTRUCTIONS

- 1. Gently turn both legs (B) upside down with inside surfaces facing each other and leave enough spaces to assemble the stretcher (C) in between, as shown in FIGURE 1.
- 2. Raise the stretcher (C) and place the rod to align against the legs (B); insert flat washer (3), lock washer (2), and Allen bolt (5) then tighten 80% with Allen wrench (4), as illustrated in FIGURE 1.
- 3. Gently turn tabletop (A) over and place on a protected surface. Attach assembled base to the top by using flat washer (3), lock washer (2), and Allen bolt (1). All hardware can be fully tightened using Allen wrench. DO NOT OVERTIGHTEN. Refer to FIGURE 2.
- 4. Turn the table to upright position and adjust levelers as needed.
- 5. Assembly is complete.

FIGURE 1




FIGURE 3





FIGURE 4



RH

VINTAGE ITALIAN TANNERY OAK DINING TABLE INSTRUCTIONS

CARE INSTRUCTIONS

- 1. Dust with a clean, soft, damp cloth and wipe dry immediately.
- 2. Avoid the use of chemicals and harsh cleaning agents.
- 3. TAKE NOTE: THE BOLTS MAY SLIGHTLY LOOSEN OVER TIME. IF YOUR FURNITURE FEELS WOBBLY OR LOOSE, PLEASE RE-TIGHTEN BOLTS.

IMPORTANT SAFETY INSTRUCTIONS

- 1. Do not place heavy objects on the table top.
- 2. Never sit on, stand on or otherwise apply heavy pressure to the top or frame.
- 3. Do not allow children to play on or around the table.