


## QUENTIN OUTDOOR PENDANT SCONCE

**PARTS ENCLOSED:**

- (A) Mounting Plate (1)
- (B) Mounting Plate Screws (2)
- (C) Wire Nuts (2)
- (D) Backplate Screws (4)
- (E) Backplate (1)
- (F) Lantern Canopy (1)
- (G) Inside Cap Location (1)
- (H) Exterior Shade (1)
- (I) Exterior Shade Frame (1)
- (J) Exterior Shade Screws (4)
- (K) Interior Shade Screws (3)
- (L) Interior Shade (1)



**IMPORTANT PLEASE READ****WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.****SAFETY INSTRUCTIONS:**

These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.


This fixture has been rated for up to one (1) 40-watt maximum Type B candelabra base bulb or one (1) 4.7-watt LED candelabra base bulb. To avoid risk of fire, do not exceed the recommended wattage.

If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.

**WARNINGS:**

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your fixture is fully assembled. To reduce the risk of fire, electrical shock or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb. Do not touch bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from the lit bulb.

This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning, or otherwise touching this light fixture.

 **WARNING:** This product can expose you to lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

**THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE.**

 **WARNING: STRANGULATION HAZARD**

Keep cord at least 3 ft away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3.

**ASSEMBLY & INSTALLATION:**

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/ CIRCUIT BREAKER.
2. Remove mounting plate (A) from backplate (E) by removing backplate screws (D). Guide wiring from outlet box through center hole in mounting plate (A).
3. Affix mounting plate (A) to the wall using mounting plate screws (B) provided.
4. Lift fixture to mounting plate (A) and make proper electrical connection.
5. Connect the copper wire from fixture to ground (green) wire. Connect white or rough side of wire from fixture to white wire from outlet box using wire nuts (C). Connect black or smooth side of wire from fixture to black wire from outlet box using wire nuts (C).
6. Align holes in backplate (E) with holes in mounting plate (A). Slide backplate (E) over mounting plate (A). Thread backplate screws (D) into backplate (E) to secure fixture to mounting plate (A).
7. Install one (1) 40-watt maximum Type B candelabra base bulb or one (1) 4.7-watt LED candelabra base bulb into socket.
8. Align exterior shade frame (I) and exterior shade (H) so shade sits inside frame.
9. Lift both pieces to lantern canopy (F). Align holes in exterior shade frame (I) and holes in exterior shade (H) with holes in tabs on lantern canopy (F). Thread exterior shade screws (J) into holes until shade is securely attached.
10. Align interior shade screws (K) with channels in inside cap (G). Turn interior shade (L) so interior shade screws (K) rest securely in channels of inside cap (G), holding the interior shade (L) in place.

**CARE INSTRUCTIONS:**

Wipe clean with a soft, dry cloth or static duster. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.