

RH

WEATHERED WOOD FLOOR LAMP

PARTS

- (A) Lamp Socket
- (B) Saddle
- (C) Harp
- (D) Lightbulb
- (E) Finial
- (F) Lamp Socket Knob
- (G) Plug

ASSEMBLY:

1. Install the Harp (C) into the Saddle (B).
2. Install the Lightbulb (D) into the Lamp Socket (A).
3. Install the Shade (sold separately) on the Harp (C).
4. Screw the Finial (E) on the top of the Harp (C).
5. Insert the Plug (G) into an electric socket.
6. Twist the Lamp Socket Knob (F) to turn on the light.

PLEASE FOLLOW THE ASSEMBLY INSTRUCTIONS CLOSELY. IMPROPER ASSEMBLY CAN RESULT IN PERSONAL OR PROPERTY DAMAGE. IF YOU ARE UNSURE ABOUT HOW TO INSTALL, CONSULT A QUALIFIED PROFESSIONAL OR YOUR LOCAL HARDWARE STORE.

