
RESTORATION HARDWARE

LARGE ROUND ROPE CHANDELIER

PARTS ENCLOSED

- (A) Mounting Plate (1)
- (B) Mounting Screws (2)
- (C) Base Screws (3)
- (D) Canopy (1)
- (E) Chain (1)
- (F) Top Loop (1)
- (G) Light bulbs (8)



IMPORTANT SAFETY INSTRUCTIONS:

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.

This fixture has been rated for up to eight (8) 40-watt maximum Type A bulbs (G) (included). To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull with wires as a bad connection may result. Do not connect electricity until your fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug fixture and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.

IMPORTANT: For a safe and secure installation, please ensure that the electrical box to which this fixture will be mounted is properly attached to a structural member of the building.

TO ASSEMBLE:

- 1. Carefully remove all parts from the box and remove all plastic covering.
- 2. Turn OFF power to the junction box where the pendant will be installed.
- 3. Remove mounting plate (A) from canopy (D) by removing base screws (C).
- 4. Affix mounting plate (A) to ceiling outlet box with mounting screws (B) provided.
- 5. Screw top loop (F) with chain (E) on top of assembly part.
- 6. Feed wire through chain (G) and canopy (D).
- Wrap both fixture safety cable and ceiling safety cable to lock nut and secure with nuts as shown
- 8. Attach the fixture ground wire to the ground wire from the outlet box (usually green or bare wire) with a plastic wire connector and wrap the connection with electrical tape.
- 9. Connect the hot wire to the hot outlet box wire (usually black) with a plastic wire connector and wrap the connection with electrical tape.
- 10. Connect the neutral wire to the neutral outlet wire (usually white) with a plastic wire connector and wrap the connection with electrical tape.
- 11. Tuck these wire connections neatly into the ceiling outlet box.
- 12. Attach canopy (D) to mounting plate (A), tighten with base screws (C).
- 13. Insert the recommended light bulbs (included) into the threaded sockets.
- 14. Restore power to the junction box and test the pendant fixture.
- 15. Assembly is complete.

CARE INSTRUCTIONS:

Wipe all surfaces with a soft dry cloth. Clean glass with a mild soap and water mixture. Do not use any harsh cleaners (including ammonia-based products) or abrasives, as they will damage the finish.