


RESTORATION HARDWARE

19TH C. FRENCH WEATHERED ZINC BALUSTER TABLE LAMP

PARTS & TOOLS

INCLUDED PARTS:	ITEM	QTY.
FINIAL	A	1
FINIAL SCREW PLATE	B	1
HARP	C	1
SADDLE	D	1
LAMP BASE	E	1



IMPORTANT SAFETY INSTRUCTIONS:

These instructions are provided for your safety. It is very important that they are read completely before beginning the installation.

For safety purposes, this lamp is equipped with a polarized plug. If the plug does not fit securely into the outlet, do not force it – contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket.

Never alter the plug in any way.

The fixture has been rated for up to (1) maximum 60-watt medium screw base TYPE A standard bulb (included) or 13-watt CFL bulb (included).

The CLF bulb is included because of the requirements of California energy efficient regulations.

To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not plug into electrical outlet until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off any unplugged lamp and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on.

Do not look directly at lit bulb.

Keep flammable materials away from lit bulb.

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Insert Harp (C) into the Saddle (D).
3. Insert (1) standard bulb or (1) CFL bulb (included) into the socket.
4. Unscrew the Finial (A) from the Finial Screw Plate (B) and place the desired shade (sold separately) over the harp.
5. Attached the finial and tighten to secure the shade.
6. Plug into proper electrical outlet and test fixture.
7. Assembly is complete.

CARE INSTRUCTIONS:

Do not use any chemical or abrasive cleaners.

WIPE CLEAN WITH SOFT CLOTH ONLY.