

RESTORATION HARDWARE

ATELIER SCISSOR TASK FLOOR LAMP

PARTS ENCLOSED:

- (A) Swivel
- (B) Housing
- (C) Threaded Tube
- (D) Base
- (E) Loader
- (F) Washer
- (G) Washer
- (H) Nut
- (I) Wrench
- (J) Polarized Plug
- (K) Adjustment Key

IMPORTANT SAFETY INSTRUCTIONS:

1. These instructions are provided for your safety. It is important that all instructions are read before beginning the fixture assembly.
2. This lamp comes with a polarized plug as a feature to reduce the risk of electrical shock. If the plug does not fit into your outlet, contact a licensed electrician.
3. NEVER alter the plug in any way.
4. Do not insert the plug into the wall outlet until the lamp is fully assembled.

TO ASSEMBLE:

1. Unpack all parts and place them on a protected work surface.
2. Place base (D) over loader (E). Align housing (B) over the center of base (D).
3. Insert threaded tube (C) into the holes in base (D) and loader (E). Pull cord taught from below the base to prevent damage to the wire.
4. Carefully hold parts together and turn lamp assembly to the side so the bottom of the base is exposed.
5. Slide washers (F) and (G) onto threaded tube (C). Thread nut (H) onto threaded tube (C) and tighten using wrench (I).
6. Carefully turn lamp assembly back into upright position.
7. Insert one 60W maximum, Type A, medium base bulb into the socket.
8. To adjust the position of the lamp, loosen adjustment key (K). Once desired placement is reached, tighten adjustment key (K) to secure position. Repeat step for each of the remaining swivels.
9. Remove protective plastic from polarized plug (J). Insert polarized plug (J) into wall outlet.

CARE INSTRUCTIONS:

1. To clean, wipe gently with a soft dry cloth. Do not use any chemical or abrasive cleaners as they may damage the finish.

