

RESTORATION HARDWARE

VENETO 8-LIGHT CHANDELIER

PARTS ENCLOSED:

- | | |
|---------------------------|-----------------|
| (A) Wire Nuts (X3) | (I) Extensions |
| (B) Cross Bar | (J) Sockets |
| (C) Cross Bar Screws (X2) | (K) Housing |
| (D) Threaded Tube | (L) Light Cover |
| (E) Hang Straight | |
| (F) Canopy | |
| (G) Collar | |
| (H) Housing | |

IMPORTANT SAFETY INSTRUCTIONS:

1. These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
2. We strongly recommend that a professional electrician install all direct wire fixtures.
3. This product must be installed in accordance with the applicable installation codes by a person familiar with the construction and operation of the product and the hazards involved.
4. The lighting fixture is meant for indoor use. It must be connected only to 3-wire, single-phase electrical supply systems (provided with ground wire or equivalent protection system).
5. This fixture has been rated for up to eight (8) 40-watt maximum, TYPE B, candelabra base light bulbs & five (5) 25-watt maximum, TYPE T6, candelabra base light bulbs. To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

1. To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulbs.
2. Do not touch bulbs when fixture is turned on. Do not look directly at lit bulbs.
3. Keep flammable materials away from lit bulbs.
4. This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and/or other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

TO ASSEMBLE:

1. SHUT OFF MAIN ELECTRICAL SUPPLY AT FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts carefully from the carton. Do not throw away any parts.
3. Measure desired drop for fixture to hang and remove/ reconfigure extension tubes (I) as needed.
TO ADD/REMOVE EXTENSIONS: (Un)Thread the threaded nipple of one extension into/ out of the threaded opening of the next extension. Make sure electrical cord is pulled tight when threading extensions together to prevent damage to the wiring.
4. Pull cord taught from above and thread bottom extension tube (I) onto the nipple exiting housing (H). Make sure hang straight (E) is threaded onto top extension (I).
5. Lower collar (G) and canopy (F) down over extensions (I) and let them rest on housing (H).
6. Attach cross bar (B) to the fixture by threading tube (D) into the top of hangstraight (E). Cut the cord to the desired length to make electrical connections. At least 8" of wire will be needed to make proper electrical connections.
7. Lift the fixture to the ceiling and attach cross bar (B) to the outlet box using mounting screws (C).
8. Pull wiring from ceiling outlet box and make proper electrical connections described in steps 9 - 11.
9. Attach ground wire from fixture (green or silver in color) to ground wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
10. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
11. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
12. Carefully push wire connections back into ceiling outlet box. Slide canopy (F) up extensions (I) and firmly hold against ceiling. Slide collar (G) up extensions (I) and thread it onto hang straight (E) to secure canopy (F) against the ceiling.
13. Insert twelve (12) 40-watt maximum, TYPE B, candelabra base bulbs into sockets (K).

DOWN LIGHT RE-LAMPING INSTRUCTIONS:

1. Remove light cover (L) from housing (K) by turning it in a counter clock wise motion.
2. Remove the old blub and replace it with a 25-watt maximum, TYPE T6, candelabra base bulb.
3. Thread light cover (L) back onto housing (K). Turn until hand tight.

CARE INSTRUCTIONS:

1. Wipe clean with a soft, dry cloth or static duster.
2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

