


RESTORATION HARDWARE

Thank you for purchasing Restoration Hardware Lighting. Our assortment is crafted with the highest quality details in mind and each collection is clad in one of our signature finish options.

PARTS ENCLOSED

- A. Lamp
- B. Saddle (Attached with Lamp base)
- C. Harp
- D. Finial



ASSEMBLING INSTRUCTIONS :

1. Insert the Harp (C) into the Saddle(B).
2. Remove the Finial (D) from Harp by moving in anti-clock wise direction.
3. Place the shade (not provided) on the threaded post of the Harp (C).
4. Now screw back the Finial (D) on threaded post of the Harp (C) by screwing it in the clock wise direction.

SHADE INSTRUCTIONS :

1. To reduce the risk of fire, use maximum 150 Watt, type A Bulb or CFL lamp maximum 23 Watt.

2. Use Open Top, Open Bottom type of shade.

3. For 150 Watt type A Bulb or CFL lamp maximum 23 Watt, the minimum lamp shade spacings are as specified.

E = 3.25 inches


F = 4.75 inches

G = 4.50 inches

Shade minimum opening area is 16 square inches.

4. Do not use the shade in this position.

5. Shade material other than metal, glass or porcelain shall be of slow burning type.



CAUTION :

1. Any Deviation from the recommended type of shade may constitute a fire hazard.