

CADIZ SEATING COLLECTION

RH





All dimensions are given in inches. See the attached "Dimensions Diagram" sheet for more information on the keys used in this chart.

	OVERALL WIDTH [A]	OVERALL DEPTH [B]	OVERALL HEIGHT W/ CUSHION [C]	FRAME HEIGHT [D]	ARM HEIGHT [E]	ARM WIDTH [F]	FOOT HEIGHT [G]	SEAT HEIGHT W/ CUSHION [H]	SEAT HEIGHT (FLOOR TO FRAME) [I]	INSIDE SEAT WIDTH [J]	INSIDE SEAT DEPTH [K]	# OF BACK CUSHIONS	# OF SEAT CUSHIONS
59" SOFA	59	34¾	27½	26½	26½	2	10	16½	12	47	30	4	1
83" SOFA	82¾	34¾	27½	26½	26½	2	10	16½	12	70¾	30	6	1
LOUNGE CHAIR	41½	34¾	27½	26½	26½	2	10	16½	12	29½	30	4	1
OTTOMAN	24	23¾	16½	12	-	-	10	16½	12	24	23¾	-	1
COFFEE OTTOMAN	35½	34	16½	12	-	-	10	16½	12	35½	34	-	1
CHAISE	27½	78	33¾	32¾	-	-	10	13¾	12¾	27½	54	1	1
SMALL DAYBED	39½	78	32½	30½	-	-	10	16¾	12¾	39½	54	1	1
MEDIUM DAYBED	55¾	78	34½	32¾	-	-	10	16¾	12¾	55¾	54	2	1
ARMLESS CHAIR	35½	34¾	27½	26½	-	-	10	16½	12	35½	30	1	1
TWO-SEAT ARMLESS SOFA	71	34¾	27½	26½	-	-	10	16½	12	71	30	4	1
TWO-SEAT LEFT-ARM SOFA	71	34¾	27½	26½	26½	2	10	16½	12	65	30	5	1
TWO-SEAT RIGHT-ARM SOFA	71	34¾	27½	26½	26½	2	10	16½	12	65	30	5	1
CORNER CHAIR	34¾	34¾	27½	26½	-	-	10	16½	12	28	28	3	1
DINING ARMCHAIR	23½	23¾	30½	25	25	2	-	18½	15½	19½	19¾	1	1

OUTDOOR SEATING DIMENSIONS DIAGRAM

See the "Dimensions Sheet" for the measurements that correspond with the letters below.





RH



OUTDOOR SEATING DIMENSIONS DIAGRAM

See the "Dimensions Sheet" for the measurements that correspond with the letters below.

RH



141¼" Left-Arm L-Sectional: 141¼"w x 105¾"d x 26½"h Overall

