

# RESTORATION HARDWARE

## PALLADIAN ARCH

Thank you for purchasing this Palladian Arch.

Made of steel protected from moisture by a powder coated finish, this arch will survive the natural elements for many seasons to come.

**NOTE: BEFORE ASSEMBLY, MAKE SURE YOU HAVE ALL PARTS LISTED BELOW.**

### *Included Parts & Hardware*

Unpack the arch on a protected, level surface and identify the following components:

#### *Arch parts:*


- A. Upper Curved Panel (2)
- B. Side Panel (2)
- C. Stakes (4)

#### *Hardware*

- D. Allen Head Screws (6)
- E. Lag Screws and Shields (4)  
- not shown

### *Tools Required for Assembly*

Allen wrench (included). Rubber mallet is necessary if you plan to anchor the arch in the soil. Power drill with bits ( $\frac{1}{2}$ " masonry bit for installing on stone or cement, or  $\frac{1}{4}$ " standard bit for installing into wood.) You will also need crescent or socket wrench.



#### *Arch parts:*

- A. Upper Curved Panel (2)
- B. Side Panel (2)
- C. Stakes (4)

#### *Hardware*

- D. Allen Head Screws (6)
- E. Lag Screws and Shields (4)  
- not shown

### *How to Assemble Your Arch*

We recommend that 2 people be on hand to assemble the arch.

1. Lay the Upper Curved Panels (A) on a level surface and align the pieces so that the uppermost parts nearly touch each other. Slide the Allen Head Screws (D) through the predrilled holes to threaded holes in the second upper curved panel and screw by means of Allen wrench.
2. With the arch top on its side, attach the Side Panels (B) to either side and screw with Allen Head Screws (D). Feet should be facing inward.
3. Tighten the screws securely. With the assistance of a second person, tip the arch upright.
4. To anchor the arch in the soil use a rubber mallet to drive the Stakes (C) through the holes in the arch's feet and into the ground.
5. For permanent placement on wood, stone or concrete, the feet should be bolted in place by means of Lag Screws and Shields (E).

To mount on wood:

- A. Mark exactly where each mounting hole should be drilled. Pre-drill holes for each foot using a  $\frac{1}{4}$ " bit.
- B. Install each foot using the Lag Screws (E).
- C. Tighten securely.

To mount on concrete, brick or stone:

- A. Mark exactly where each mounting hole should be drilled. Pre-drill holes for each foot using a  $\frac{1}{2}$ " masonry bit.
- B. Insert Lag Shields (E) into the predrilled holes and tap with a hammer so they are flush with the ground surface. Then install the feet by inserting the Lag Screws (E) through the feet and into the shields.
- C. Tighten securely.

### *Caring for Your Palladian Arch*

This powder-coated steel garden structure is resistant to the effects of sun, rain, frost, and snow. It may be left outdoors year-round. To clean, simply wipe with a damp cloth. If the powder-coat finish should chip or scratch, it may be touched up with rust-proof enamel (not included).