

# RESTORATION HARDWARE

Thank you for purchasing Restoration Hardware Lighting. Our assortment is crafted with the highest quality details in mind and each collection is clad in one of our signature finish options. Each item's surface is sealed which eliminates the need for polishing and ensures the lasting brilliance of your piece for years to come.

## PARTS ENCLOSED:

- (A) Fix Screw (2)
- (B) Canopy (1)
- (a) Wire Connector (3)
- (b) Mounting Plate (1)
- (c) Dimple (2)
- (d) Green Ground Screw (1)
- (e) Outlet Box Screw (2)
- (f) Ground Wire (1)

## IMPORTANT SAFETY INSTRUCTIONS :

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.  
This fixture has been rated for up to (1) 100-watt maximum TYPE A bulb.  
To avoid the risk of fire, do not exceed the recommended wattage.

## WARNINGS :


All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.

Keep flammable materials away from lit bulb.

## MADERA OUTDOOR PENDANT



## TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Turn OFF power to the junction box where the lamp will be installed.
3. Attach the ground wire (f) from the fixture to the ground junction box wire from the outlet box. (usually green or bare wire) with a plastic Wire Connector (a) and wrap the connection with electrical tape. Screw the green ground screw (d) onto the mounting plate (b) near the dimples (c) , and wrap the fixture's bare ground wire around the ground screw. Then, tighten the screw.
4. Connect the hot wire to the hot junction box wire (usually black) with a plastic wire connector (a) and wrap the connection with electrical tape. Connect the neutral wire to the neutral junction box wire (usually white) with a plastic wire connector (a) and wrap the connection with electrical tape
5. Attach the mounting plate (b) to the outlet box using the outlet box screws (e). Tighten with a screwdriver.
6. Attach the canopy (B) to the mounting plate (b), and fix with the enclosed fix screws (A) using a screwdriver.
7. Insert 100 watt Type A bulb (not included) into the threaded socket.■
8. Restore power to the junction box and test lamp fixture.
9. Assembly is complete.

## Direct Wire Installation

## CARE INSTRUCTIONS :

Do not use polishes or cleaners on your lamp.  
JUST WIPE CLEAN WITH SOFT CLOTH.

# RESTORATION HARDWARE

Thank you for purchasing Restoration Hardware Lighting. Our assortment is crafted with the highest quality details in mind and each collection is clad in one of our signature finish options. Each item's surface is sealed which eliminates the need for polishing and ensures the lasting brilliance of your piece for years to come.

## PARTS ENCLOSED:

- (A) Fix Screw (2)
- (a) Wire Connector (3)
- (B) Canopy (1)
- (b) Mounting Plate (1)
- (c) Dimple (2)
- (d) Green Ground Screw (1)
- (e) Outlet Box Screw (2)
- (f) Ground Wire (1)

## IMPORTANT SAFETY INSTRUCTIONS :

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.  
This fixture has been rated for up to (1) 100-watt maximum TYPE A bulb.  
To avoid the risk of fire, do not exceed the recommended wattage.

## WARNINGS :

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your fixture is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug fixture and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.

Keep flammable materials away from lit bulb.


## TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Turn OFF power to the junction box where the fixture will be installed.
3. Attach the ground wire (f) from the fixture to the ground junction box wire from the outlet box. (usually green or bare wire) with a plastic wire connector (a) and wrap the connection with electrical tape. Screw the green ground screw (d) onto the mounting plate (b) near the dimples (c), and wrap the fixture's bare ground wire around the ground screw. Then, tighten the screw.
4. Connect the hot wire to the hot junction box wire (usually black) with a plastic wire connector (a) and wrap the connection with electrical tape. Connect the neutral wire to the neutral junction box wire (usually white) with a plastic wire connector (a) and wrap the connection with electrical tape.
5. Attach the mounting plate (b) to the outlet box using the outlet box screws (e). Tighten with a screwdriver.
6. Attach the canopy (B) to the mounting plate (b), and fix with the enclosed fix screws (A) using a screwdriver.
7. Insert 100 watt Type A bulb (not included) into the threaded socket.
8. Restore power to the junction box and test fixture fixture.
9. Assembly is complete.

## CARE INSTRUCTIONS :

Do not use polishes or cleaners on your lamp.  
JUST WIPE CLEAN WITH SOFT CLOTH.

## 16" MADERA OUTDOOR PENDANT



## Direct Wire Installation