















RESTORATION HARDWARE

30" DIA.3-TIER CAPIZ CHANDELIER

PARTS REQUIRED:

ITEMS	DIAGRAM	DESCRIPTION	QTY.
(A)		green ground screw	1 pc.
(B)		crossbar	1 pc.
(C)		j-box mounting screws	2 pcs
(D)		plastic wire connectors	3 pcs
(E)		canopy	1 pc.
(F)		canopy crown washers	2 pcs
(G)		canopy screws	2 pcs.
(H)		metal frame	1 pc.
(I)		socket	3 pcs.
(J)		bulbs (not included)	3 pcs.
(K)		chain	6 ft
(L)		quick link	1 pc
(M)		capiz strands	245 pcs
(N)		lampholder frame	1 pc

CAUTION:

BEFORE INSTALLING FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

IMPORTANT SAFETY INSTRUCTIONS:

1. These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
2. We strongly recommend that a professional electrician install all direct wire fixtures.
3. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
4. The lighting fixture is meant for indoor use. It must be connected only to 3-wire, single-phase electrical supply systems (provided with Ground wire or equivalent protection system).
5. For your safety, it is strongly recommended that two people install and hang the lighting fixture.
6. This fixture has been rated for up to (3) 60-watt maximum TYPE A standard incandescent light bulb (not included). To avoid the risk of fire, do not exceed the recommended wattage.
7. The lighting fixture is meant for indoor use, DRY LOCATION ONLY.
8. Save these instructions.

WARNING:

1. To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.
2. Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
3. Keep flammable materials away from lit bulb.
4. All wires are connected. Do not remove the metal frame from its packaging by pulling on the power cord, as bad connection may result.

PRE-ASSEMBLY:

1. Remove all parts and hardware from box along with any plastic protective packaging.
2. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
3. For your safety and convenience, assembly by two people is recommended.

INSTALLATION INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER!
2. Carefully unpack all fixture parts and hardware and lay out on a clear workspace.
3. Separate Crossbar (B) from Canopy (E) by removing the two Canopy Screws (G) and two Canopy Crown Washers (F). Do not discard Canopy Screws (G) and Canopy Crown Washers (F) as these will be used later.
4. Gently pull existing wire down from the ceiling junction box and allow it to hang.
5. Carefully inspect the Fixture's wires. The NEUTRAL FIXTURE WIRE is White insulation. The HOT FIXTURE WIRE is Black insulation, and the GROUND WIRE is Green-Yellow insulation.
6. Attach the GROUND WIRE from the fixture to the GROUND JUNCTION BOX WIRE from the outlet junction box (J-box) (usually green insulation or bare wire). Fasten each together with a Plastic Wire Connector (D) by twisting the connector in clockwise direction and wrapping the connection with electrical tape. Be sure that no wire strands are exposed. If your outlet junction box DOES NOT have a GROUND WIRE, be sure to insert the Green Ground Screw (A) into the Crossbar (B) marked as "GND", and wrap the fixture's bare ground wire around the Green Ground Screw (A). IT IS IMPERATIVE THAT THE JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED!
7. Connect the NEUTRAL FIXTURE WIRE to the NEUTRAL JUNCTION BOX WIRE (usually white insulation). Fasten each together with a Plastic Wire Connector (D) by twisting the connector in clockwise direction and wrapping the connection with electrical tape. Be sure that no wire strands are exposed.
8. Connect the HOT FIXTURE WIRE to the HOT JUNCTION BOX WIRE (usually black insulation). Fasten each together with a Plastic Wire Connector (D) by twisting the connector in clockwise direction and wrapping the connection with electrical tape. Be sure that no wire strands are exposed. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
9. Gently tuck the wire connections neatly into the ceiling junction box.
10. Attach the Crossbar (B) to the ceiling outlet box using the J-box Mounting Screws (C). Tighten screws with a screwdriver.
11. Pull Canopy (E) up over the Crossbar (B) aligning the holes in the Crossbar (B) with the two holes on the side of the Canopy (E).
12. Insert the 2 Canopy Screws (G) with Canopy Crown Washers (F) and tighten with a screwdriver.
13. Insert (3) 60 watt maximum TYPE A standard incandescent light bulb(J) (not included) into the Socket (I). DO NOT EXCEED SPECIFIED WATTAGE.
14. Hang the capiz strands (M) from top layer to bottom layer (see fig. 1,2&3). To ensure safety of chandelier during capiz installation, please maintain level of chandelier by ensuring you install capiz strands in balanced way on opposite ends of light.
15. Restore power to junction box and test fixture.
16. Installation is complete.

CARE INSTRUCTIONS:

1. Always turn off power to fixture. Wipe clean with a soft, dry cloth or static duster.
2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

