


RESTORATION HARDWARE

VITTI MIRRORED TWO-TIER RECTANGULAR CHANDELIER 48" L - ANTIQUE MIRROR

PARTS ENLOSED

ITEMS	DIAGRAM	DESCRIPTION	QTY.
(A)		Ceiling Plate	1
(B)		Canopy	1
(C)		Screw+spare	20+5
(D)		Anchors+spare	20+5
(E)		Hang straight	2
(F)		Allen Bolt	2
(G)		Allen Key	1
(H)		Chain	2
(I)		Bulb Fixture	2
(J)		TYPE-A Bulb (Not included)	6
(K)		Body-1	1
(L)		Body-2	1



IMPORTANT SAFETY INSTRUCTION:

1. Use an authorized and certified electrician for consultation and installation. Electrician must be familiar with commercial-type applications of very heavy chandeliers.
2. This fixture has been rated for 6 x 60-Watt maximum E26 standard bulb.
3. To avoid the risk of fire, do not exceed the recommended wattage.
4. The ceiling must have at least the capacity of 5 times the weight of the ceiling light. For this light at least a ceiling capacity of 133 kgs. is required.
5. The manufacturer and distributor accept no liability for incorrect installation.
6. For indoor use only.
7. Keep away from children.

WARNINGS:

1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your ceiling light is fully assembled and installed.
2. To reduce the risk of fire, electrical shock, or personal injury, always turn off the ceiling light and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
3. Deviation from instructions may result in a risk of fire or electric shock. Please read all instructions completely before starting installation.
4. This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and/or other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Turn OFF power to the junction box where the ceiling light will be installed.
3. Loosen the Hang straight (E) from ceiling plate (A) and canopy (B). Then unfasten the Allen bolt (F) with help of Allen key (G) to detach ceiling plate (A) and canopy (B).
4. Drill 20 holes on the ceiling corresponding with holes in ceiling plate (A) then knock the screw anchors (D) into the holes. Attach the ceiling plate (A) to the ceiling with screws (C). Note: Anchors are used for concrete ceiling, for wooden ceiling only screws can be used.
5. Attached the Bulb fixture (I) from the bottom of body-1 (K) as shown in image and connect the ground wire from the fixture (I) passing through the hole in canopy (B) to ground junction box wire (not included).
6. Attached the canopy (B) with ceiling plate (A) and tighten the Allen bolt (F) with help of Allen key (G). Then fasten the hang straight (E) to the threaded bolt passing through the canopy (B) as shown in image.
7. Insert 6 Type A bulbs (not included) into the socket. Do not exceed specified wattage.
8. Hang the Body-2 (L) on the Body-1 (K) as shown in image.
9. Restore power to the junction box and test ceiling light fixture.

CARE INSTRUCTIONS:

1. Make sure that the power is turned off and bulb has cooled before handling.
2. Wipe clean with a dry cloth / static duster. Do not use corrosive cleaners.