

RESTORATION HARDWARE

19TH C. CASBAH CRYSTAL CHANDELIER SMALL

PARTS ENCLOSED :

- (B) CROSS BAR WITH GROUNDING SCREW
- (C) CEILING ROSE
- (D) RETAINING NUT
- (E) CEILING LOOP
- (F) HOOK (attached to Metal Chain)
- (G) METAL CHAIN
- (H) POWER CORD
- (I) GROUND WIRE
- (J) HOOK (attached to metal Chain)
- (K) LOOP IN PENDANT
- (L) SCREWS
- (M) PENDANT

IMPORTANT SAFETY INSTRUCTIONS :

* These instructions are provide for your safety. It is very important that they are properly read **completely** before beginning the installation of your fixture.

DIRECT WIRE FIXTURE.

WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.

WARNINGS :

Turn off power (unplug from the wall outlet) before replacing the bulb, making sure, The bulb had sufficient time to cool down. DO NOT subject the lamp to any shock while lit as shattering of lamp may result.

TO ASSEMBLE :

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX / CIRCUIT BREAKER
2. Remove all parts from carton. Do not throw away any parts.
3. Check if the grommets have been inserted in components **Cross Bar (B)** and **Ceiling Loop (E)**. If not insert this yourself.
4. Un-screw the **Cross Bar (B)** from the **Ceiling Loop (E)**. Affix the **Cross Bar (B)** directly to the **Junction Box** using screws provided.
5. Open the metal cover on top of crystal ball by unscrewing the three **Screws (L)** and take out the light hub. Assemble one, Type A Lamp into the socket of the **Pendant (M)** Now lower the light hub back and place it in the crystal ball and screw back the three **Screws (L)**.
6. Open the wire coil- **Power Cord (H)** and the **Ground Wire (I)** coming out from the **Pendant (M)** and lay them together and parallel to each other.
7. Attach the **Hook (J)** on one side of the chain to the **Pendant Loop (K)** in the **Pendant (M)**
8. Weave the wires **Power Cord (H)** and the **Ground Wire (I)** through the **Metal Chain (G)** -taking the wires through alternate links of the **Metal Chain (G)**.
9. Lift carefully the **Pendant (M)** with one end of the **Metal Chain (G)** attached to it and place it in one elevated position (e.g on a step ladder) in such a way that the wire cords can freely reach the ceiling Junction box.
10. Guide the wires- coming out from the **Pendant (M)** and running woven through the **Metal Chain (G)** - through the **Ceiling Loop (E)**, **Retaining Nut (D)** and the **Ceiling Rose (C)** in the order mentioned.
11. Further guide the wires through the **Threaded Tube** of the **Cross Bar (B)**.
12. Now you can see the wire coming out from the **Cross Bar (B)**
13. **MAKE PROPER ELECTRICAL CONNECTIONS. THIS INSTALLATION SHOULD BE DONE BY A QUALIFIED LICENSED ELECTRICIAN. ELECTRICAL CONNECTIONS SHALL BE MADE LIVE TO LIVE AND NEUTRAL TO NEUTRAL.**
14. Connect the Grounding Wire (silver colour un-laminated wire) from the **Pendant (M)** to the **Grounding Bolt (painted Green Colour)** attached to the **Cross Bar (B)**
15. Fasten wires together with a plastic Wire Connector (not provided) as follows :- Connect the Neutral Wire of the **Pendant (M)** to the Neutral Wire in the outlet box through the Wire Connector. Connect the Live Wire of the **Pendant (M)** to the Live Wire in the outlet box through the Wire Connector. Tightly wrap Wire Connector with the electrical insulation tape.
16. Slide the **Ceiling Rose (C)** and place it over the **Cross Bar (B)**. Screw the **Ceiling Loop (E)** along with the **Retaining Nut (D)** to the Threaded Pipe of **Cross Bar (B)**. Now screw the **Retaining Nut (D)** upwards so that the **Ceiling Rose (C)** is in contact with the ceiling.
17. Attach the **Hook (F)** of the **Metal Chain (G)** to the **Ceiling Loop (E)**
18. Check weather the connection is sufficiently strong by manually loading the **Metal Chain (G)**.
19. Carefully lower the **Pendant (M)** along with the **Metal Chain (G)** until the **Metal Chain (G)** is taut. Straighten the **Metal Chain (G)** links.

