


# RESTORATION HARDWARE

## VINCENT TASK TABLE LAMP

### PARTS ENCLOSED:

- |                 |                    |
|-----------------|--------------------|
| (A) Shade       | (E) Wrench         |
| (B) Column      | (F) Rotary Switch  |
| (C) Base        | (G) Polarized Plug |
| (D) Screws (X2) | (H) 23W CFL Bulb   |



### IMPORTANT SAFETY INSTRUCTIONS:

1. These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
2. This lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into the outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.
3. This fixture has been rated for up to one 60-watt maximum TYPE B, medium base light bulb or one 23-watt, medium base CFL bulb (included). To avoid the risk of fire, do not exceed the recommended wattage.

### WARNINGS:

1. To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulbs.
2. Do not touch bulbs when fixture is turned on. Do not look directly at lit bulbs.
3. Keep flammable materials away from lit bulbs.

### TO ASSEMBLE:

NOTE: Do not connect electricity until lamp is fully assembled.

1. Unpack all parts and place them on a level work surface. Remove and discard all packing materials.
2. Use wrench (E) to remove screws (D) from the back of base (C).
3. Place column (B) into the opening in base (C). Thread screws (D) into the back of base (C) to secure position of column (B). Use wrench (E) to tighten screws (D).
4. Insert one 23-watt, medium base CFL bulb (H), located inside shade (A).
5. Insert polarized plug (G) into wall outlet.
6. Control power to lamp by using rotary switch (F).

### CARE INSTRUCTIONS:

1. Wipe clean with a soft, dry cloth or static duster.
2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.